

**EMISSION CONTROLS 4-2**  
POSITIVE CRANKCASE VENTILATION  
SYSTEM 4-2  
OPERATION 4-2  
TESTING 4-2  
REMOVAL & INSTALLATION 4-2  
EVAPORATIVE EMISSION  
CONTROLS 4-2  
OPERATION 4-2  
REMOVAL & INSTALLATION 4-3  
EXHAUST GAS RECIRCULATION SYSTEM  
4-3  
OPERATION 4-3  
COMPONENT TESTING 4-4  
REMOVAL & INSTALLATION 4-4  
**ELECTRONIC ENGINE  
CONTROLS 4-6**  
POWERTRAIN CONTROL MODULE  
(PCM) 4-6  
OPERATION 4-6  
OXYGEN SENSOR 4-6  
OPERATION 4-6  
TESTING 4-7  
REMOVAL & INSTALLATION 4-7  
IDLE AIR CONTROL VALVE 4-8  
OPERATION 4-8  
TESTING 4-8  
REMOVAL & INSTALLATION 4-8  
ENGINE COOLANT TEMPERATURE (ECT)  
SENSOR 4-8  
OPERATION 4-8  
TESTING 4-8  
REMOVAL & INSTALLATION 4-9  
INTAKE AIR TEMPERATURE  
SENSOR 4-10  
OPERATION 4-10  
TESTING 4-10  
REMOVAL & INSTALLATION 4-10  
MASS AIRFLOW SENSOR 4-10  
OPERATION 4-10  
TESTING 4-11  
REMOVAL & INSTALLATION 4-11  
MANIFOLD AIR PRESSURE (MAP)  
SENSOR 4-11  
OPERATION 4-11  
TESTING 4-11  
REMOVAL & INSTALLATION 4-12  
THROTTLE POSITION SENSOR 4-12  
OPERATION 4-12  
TESTING 4-12  
REMOVAL & INSTALLATION 4-12  
CAMSHAFT POSITION SENSOR 4-12  
TESTING 4-12  
REMOVAL & INSTALLATION 4-12  
CRANKSHAFT POSITION SENSOR 4-13  
OPERATION 4-13  
TESTING 4-13  
REMOVAL & INSTALLATION 4-13  
**COMPONENT LOCATIONS 4-14**  
**TROUBLE CODES —EEC-IV  
SYSTEM 4-17**

GENERAL INFORMATION 4-17  
FAILURE MODE EFFECTS  
MANAGEMENT (FMEM) 4-17  
HARDWARE LIMITED OPERATION  
STRATEGY (HLOS) 4-17  
DIAGNOSTIC LINK CONNECTOR 4-17  
HAND-HELD SCAN TOOLS 4-17  
ELECTRICAL TOOLS 4-17  
READING CODES 4-18  
VISUAL INSPECTION 4-18  
ELECTRONIC TESTING 4-18  
CLEARING CODES 4-21  
CONTINUOUS MEMORY  
CODES 4-21  
KEEP ALIVE MEMORY 4-21  
**TROUBLE CODES —EEC-V SYSTEM  
(OBD-II) 4-21**  
GENERAL INFORMATION 4-21  
MALFUNCTION INDICATOR LAMP 4-22  
DATA LINK CONNECTOR 4-22  
ELECTRICAL TOOLS 4-22  
READING CODES 4-22  
CLEARING CODES 4-22  
CONTINUOUS MEMORY  
CODES 4-22  
KEEP ALIVE MEMORY 4-22  
EEC-V DIAGNOSTIC TROUBLE CODES  
(DTC'S) 4-22  
**VACUUM DIAGRAMS 4-27**  
**COMPONENT LOCATIONS**  
COMMON EMISSIONS AND  
ELECTRONIC ENGINE CONTROL  
COMPONENT LOCATIONS—3.8L  
ENGINE 4-14  
COMMON EMISSIONS AND  
ELECTRONIC ENGINE CONTROL  
COMPONENT LOCATIONS—4.6L  
ENGINE 4-15  
COMMON EMISSIONS AND  
ELECTRONIC ENGINE CONTROL  
COMPONENT LOCATIONS—5.0L  
ENGINE 4-16

# 4

## DRIVEABILITY AND EMISSIONS CONTROLS

EMISSION CONTROLS 4-2  
ELECTRONIC ENGINE CONTROLS 4-6  
COMPONENT LOCATIONS 4-14  
TROUBLE CODES—EEC-IV  
SYSTEM 4-17  
TROUBLE CODES—EEC-V SYSTEM  
(OBD-II) 4-21  
VACUUM DIAGRAMS 4-27

## EMISSION CONTROLS

### Positive Crankcase Ventilation System

The Positive Crankcase Ventilation (PCV) system is used on all vehicles covered by this manual. The PCV system vents harmful combustion blow-by fumes from the engine crankcase into the engine air intake for burning with the fuel and air mixture. The PCV system maximizes oil cleanliness by venting moisture and corrosive fumes from the crankcase.

#### OPERATION

##### ▶ See Figure 1

Your car is equipped with a closed Positive Crankcase Ventilation (PCV) system. The PCV system vents crankcase gases into the engine air intake where they are burned with the air/fuel mixture. The PCV system keeps pollutants from being released into the atmosphere, and also helps to keep the engine oil clean, by ridding the crankcase of moisture and corrosive fumes. The PCV system consists of the PCV valve, a closed oil fill cap and the various connecting hoses.

The PCV system recycles crankcase gases as follows: When the engine is running, clean filtered air is drawn into the crankcase through the intake air filter. As the air passes through the crankcase, it picks up the combustion gases and carries them out of the crankcase, up through the PCV valve and into the intake manifold. After they enter the intake manifold, they are drawn into the combustion chamber and burned.

The most critical component of the PCV system is the PCV valve. The PCV valve regulates the amount of ventilating air and blow-by gas to the intake manifold and also prevents backfire from traveling into the crankcase, avoiding the explosion of crankcase gases. At low engine speeds, the PCV valve is partially closed, limiting the flow of gases into the intake manifold. As engine speed increases, the valve opens to admit greater quantities of gases into the intake manifold.

If the PCV valve becomes blocked or plugged, crankcase gases will not be able to escape by the normal route. Since these gases are under pressure,

they will seek an alternate route, which is usually an oil seal or gasket. As the gases escape, an oil leak will be created.

Besides causing oil leaks, a clogged PCV valve will also allow gases to remain in the crankcase for an extended period, promoting the formation of sludge in the engine.

#### TESTING

1. Visually inspect the PCV valve hose and the fresh air supply hose and their attaching nipples or grommets for splits, cuts, damage, clogging, or restrictions. Repair or replace, as necessary.
2. If the hoses pass inspection, remove the PCV valve from its mounting grommet. Shake the PCV valve and listen or feel for the rattle of the valve plunger within the valve body. If the valve plunger does not rattle, the PCV valve must be cleaned or replaced. If the valve plunger rattles, the PCV valve is okay; reinstall it.
3. Start the engine and bring it to normal operating temperature. Remove the fresh air supply hose from the air cleaner or air outlet tube. Place a stiff piece of paper over the hose end and wait 1 minute. If vacuum holds the paper in place, the system is okay.
4. On the 4.6L engine, the PCV system is connected with the evaporative emission system. If the paper is not held in place, disconnect the evaporative hose, cap the connector and retest. If vacuum now holds the paper in place, the problem is in the evaporative emission system.
5. If the paper is not held by vacuum, check the fresh air and PCV hoses for leaks or loose connections. Also, check for a loose fitting oil fill cap or loose dipstick. Correct as required until vacuum can be felt at the end of the supply hose.

**⇒ If air pressure and oil or sludge is present at the end of the fresh air supply hose, the engine has excessive blow-by and cylinder bore or piston ring wear.**

#### REMOVAL & INSTALLATION

Refer to Section 1 for removal and installation of the PCV valve.

### Evaporative Emission Controls

#### OPERATION

The evaporative emission control system prevents the escape of fuel vapors to the atmosphere under hot soak and engine off conditions by storing the vapors in a carbon canister. Then, with the engine warm and running, the system controls the purging of stored vapors from the canister to the engine, where they are efficiently burned.

Evaporative emission control components consist of the carbon canister, purge valve(s), vapor valve, rollover vent valve, check valve and the necessary lines. All vehicles may not share all components.

#### OBD-II EVAP System Monitor

Some of the models covered in this manual have added system components due to the EVAP system monitor incorporated in the OBD-II engine control system. A pressure sensor is mounted on the fuel tank which measures pressure inside the tank, and a purge flow sensor measures the flow of the gases from the canister into the engine. The purge valve is now called the Vapor Management Valve (VMV). It performs the same functions as the purge valve, however it looks slightly different. A canister vent solenoid is mounted on the canister, taking the place of the vent cap, providing a source of fresh air to the canister.

The PCM can store trouble codes for EVAP system performance, a list of the codes is provided later in this section. Normal testing procedure can be used, see EVAP System Component Testing in this Section.

#### Carbon Canister

##### ▶ See Figure 2

The carbon canister contains vapor absorbent material to facilitate the storage of fuel vapors. Fuel vapors flow from the fuel tank to the canister, where they are stored until purged to the engine for burning.

#### Purge Control Valve

##### ▶ See Figure 3

The purge valves control the flow of fuel vapor from the carbon canister to the engine. Purge




Fig. 1 PCV system functional diagram




Fig. 2 Cross-section of a carbon canister




Fig. 3 Purge control valve

valves are either vacuum or electrically controlled. When electrically controlled, a purge valve is known as a purge solenoid. A vehicle may be equipped with a vacuum purge valve or purge solenoid or a combination of the two. Purging occurs when the engine is at operating temperature and off idle.

### Fuel Tank Vapor Orifice and Roll over Valve Assembly

▶ See Figure 4

Fuel vapor in the fuel tank is vented to the carbon canister through the vapor valve assembly. The valve is mounted in a rubber grommet at a central location in the upper surface of the fuel tank. A vapor space between the fuel level and the tank upper surface is combined with a small orifice and float shut-off valve in the vapor valve assembly to prevent liquid fuel from passing to the carbon canister. The vapor space also allows for thermal expansion of the fuel. The vapor valve incorporates the rollover valve. In the event of a vehicle rollover, the valve blocks the vapor line automatically to prevent fuel leakage.

The check valve is located in the fuel filler cap or on the underside of the vehicle. Its function is to protect the fuel tank from heat build-up rupture and cool-down collapse by allowing air to pass in or out of the tank to equalize pressure. On cool-down, air enters either at the carbon canister vent or at the check valve.




Fig. 5 Purge solenoid valve

through the atmosphere. The vacuum relief valve opens after a vacuum of  $\pm 0.5$  psi. The pressure valve acts as a backup pressure relief valve in the event the normal venting system is overcome by excessive generation of internal pressure or restriction of the normal venting system. The pressure relief range is 1.6–2.1 psi. Fill cap damage or contamination that stops the pressure vacuum valve from working may result in deformation of the fuel tank.

### REMOVAL & INSTALLATION

#### Carbon Canister

1. Disconnect the negative battery cable.
2. Label and disconnect the vapor hoses from the carbon canister.
3. Remove the canister attaching screws and remove the canister.
4. Installation is the reverse of the removal procedure.

#### Fuel Tank Vapor Orifice and Roll over Valve Assembly

1. Disconnect the negative battery cable.
2. Remove the fuel tank as described in Section 5.
3. Remove the vapor orifice and roll over valve assembly from the fuel tank.
4. Installation is the reverse of the removal procedure.

#### Purge Control Valve

1. Disconnect the negative battery cable.
2. Label and disconnect the hoses from the purge control valve.
3. Remove the purge control valve.
4. Installation is the reverse of the removal procedure.

#### Purge Solenoid Valve

1. Disconnect the negative battery cable.
2. Label and disconnect the hoses from the purge solenoid valve.
3. Disconnect the electrical connector from the valve.
4. Remove the purge solenoid valve.
5. Installation is the reverse of the removal procedure.

## Exhaust Gas Recirculation System

### OPERATION

▶ See Figures 6, 7, 8 and 9

The Exhaust Gas Recirculation (EGR) system is designed to reintroduce exhaust gas into the combustion cycle, thereby lowering combustion temperatures and reducing the formation of nitrous oxide. This is accomplished by the use of an EGR valve that opens under specific engine operating conditions, to admit a small amount of exhaust gas into the intake manifold, below the throttle plate. The exhaust gas mixes with the incoming air charge and displaces a portion of the oxygen in the air/fuel mixture entering the combustion chamber. The exhaust gas does not support combustion, but it takes up volume, the net effect is to lower the temperature of the combustion chamber. There are a few different EGR systems used.

The most commonly used system is the Pressure Feedback Electronic (PFE) system. The PFE is a subsonic closed loop EGR system that controls EGR flow rate by monitoring the pressure drop across a remotely located sharp-edged orifice. The system uses a pressure transducer as the feedback device and controlled pressure is varied by valve modulation using vacuum output of the EGR Vacuum Regulator (EVR) solenoid. With the PFE system, the EGR valve only serves as a pressure regulator rather than a flow-metering device.




Fig. 4 Fuel tank vapor orifice and roll over valve assembly

### Purge Solenoid Valve

▶ See Figure 5

The purge solenoid valve is in-line with the carbon canister and controls the flow of fuel vapors out of the canister. It is normally closed. When the engine is shut off, the vapors from the fuel tank flow into the canister. After the engine is started, the solenoid is engaged and opens, purging the vapors into the engine. With the valve open, vapors from the fuel tank are routed directly into the engine.

### Pressure/Vacuum Relief Fuel Cap

The fuel cap contains an integral pressure and vacuum relief valve. The vacuum valve acts to allow air into the fuel tank to replace the fuel as it is used, while preventing vapors from escaping the tank




Fig. 6 Pressure Feedback Electronic (PFE) EGR system schematic





Fig. 7 Differential Pressure Feedback Electronic (DPFE) EGR system schematic

# 4-4 DRIVEABILITY AND EMISSIONS CONTROLS




**Fig. 8 Electronic EGR (EEGR) system schematic**

The Differential Pressure Feedback Electronic (DPFE) EGR system operates in the same manner except it directly monitors the pressure drop across the metering orifice. This allows for a more accurate assessment of EGR flow requirements.

The Electronic EGR (EEGR) valve system is used on some vehicles equipped with the 5.0L engine. An electronic EGR valve is required in EEC systems where EGR flow is controlled according to computer demands by means of an EGR Valve Position (EVP) sensor attached to the valve. The valve is operated by a vacuum signal from the electronic vacuum regulator that actuates the valve diaphragm. As supply vacuum overcomes the spring load, the diaphragm is actuated. This lifts the pintle off of its seat allowing exhaust gas to recirculate. The amount of flow is proportional to the pintle position. The EVP sensor mounted on the valve sends an electrical signal of its position to the PCM.

The Pressure Feedback Electronic (PFE) EGR Transducer converts a varying exhaust pressure signal into a proportional analog voltage that is digitized by the PCM. The PCM uses the signal



**Fig. 9 View of the EGR system components—late model 3.8L engine shown**

received from the PFE transducer to compute the optimum EGR flow.

The EGR Vacuum Regulator (EVR) is an electromagnetic device that controls vacuum output to the EGR valve. The EVR replaces the EGR solenoid vacuum vent valve assembly. An electric current in the coil induces a magnetic field in the armature. The magnetic field pulls the disk back, closing the vent and increasing the vacuum level. The vacuum source is either manifold or ported vacuum. As the duty cycle is increased, an increased vacuum signal goes to the EGR valve.

## COMPONENT TESTING

Many of the following testing procedures require the use of a breakout box tool for EEC systems diagnosis. SUPER STAR II tester or NEW GENERATION STAR (NGS) tester or equivalent scan tools.

### DPFE Sensor

1. Disconnect the pressure hoses at the DPFE sensor.
2. Connect a hand vacuum pump to the downstream pickup marked **REF** on the sensor.
3. Using a multimeter, backprobe the SIG RTN circuit at the DPFE connector.
4. With the ignition **ON**, signal voltage should be 0.20–0.70 volts.
5. Apply 8–9 in. Hg of vacuum to the sensor. Voltage should be greater than 4 volts.
6. Quickly release the vacuum from the sensor. Voltage should drop to less than 1 volt in 3 seconds.
7. If the sensor does not respond as specified, check the power and ground circuits.
8. If power and ground circuits are functional, the sensor is faulty.

### EGR Valve Control Solenoid

1. Remove the EVR solenoid.
2. Attempt to lightly blow air into the EVR solenoid.
  - a. If air blows through the solenoid, replace the solenoid with a new one.
  - b. If air does not pass freely through the solenoid, continue with the test.
3. Apply battery voltage (approximately 12 volts) and a ground to the EVR solenoid electrical terminals. Attempt to lightly blow air, once again, through the solenoid.
  - a. If air does not pass through the solenoid, replace the solenoid with a new one.
  - b. If air does not flow through the solenoid, the solenoid is OK.
4. If the solenoid is functional but the problem still exists, check the power and ground circuits.

### EGR Valve

1. Install a tachometer on the engine, following the manufacturer's instructions.
2. Detach the engine wiring harness connector from the Idle Air Control (IAC) solenoid.
3. Disconnect and plug the vacuum supply hose from the EGR valve.
4. Start the engine, then apply the parking brake, block the rear wheels and position the transmission in Neutral.
5. Observe and note the idle speed.

If the engine will not idle with the IAC solenoid disconnected, provide an air bypass to the engine by slightly opening the throttle plate or by creating an intake vacuum leak. Do not allow the idle speed to exceed typical idle rpm.


6. Using a hand-held vacuum pump, slowly apply 5–10 in. Hg (17–34 kPa) of vacuum to the EGR valve nipple.
  - a. If the idle speed drops more than 100 rpm with the vacuum applied and returns to normal after the vacuum is removed, the EGR valve is OK.
  - b. If the idle speed does not drop more than 100 rpm with the vacuum applied and return to normal after the vacuum is removed, inspect the EGR valve for a blockage; clean it if a blockage is found. Replace the EGR valve if no blockage is found, or if cleaning the valve does not remedy the malfunction.

## REMOVAL & INSTALLATION


### DPFE Sensor

See Figures 10, 11, 12, 13 and 14

1. Disconnect the negative battery cable.
  2. Label and disconnect the wiring harness from the DPFE sensor.
  3. Label and disconnect the vacuum hoses.
  4. Remove the mounting screws and remove the DPFE sensor.
- To install:**
5. Position the DPFE sensor and tighten the mounting screws.



**Fig. 10 Detach the connector for the DPFE sensor**




**Fig. 11 Matchmark and remove the vacuum hoses for the DPFE sensor and . . .**





91194P39

**Fig. 12 . . . remove the retaining nuts from the DPFE sensor and . . .**



91194P40

**Fig. 13 . . . remove the DPFE sensor from the intake manifold**



93144P07

**Fig. 14 Location of PFE sensor. Also note the EGR valve behind it. Lubricating the fasteners before removal**

6. Attach all necessary hoses and wiring to the sensor.
7. Connect the negative battery cable.

### EGR Valve Control Solenoid

♦ See Figures 15, 16, 17, 18 and 19

1. Disconnect the negative battery cable.
2. Label and detach the vacuum hoses from the EVR solenoid.
3. Detach the electrical connector from the solenoid.
4. Remove the retaining hardware, and remove the solenoid.

#### To install:

5. Position the solenoid and install the retaining hardware.

6. Attach the main emission vacuum control connector and the wiring harness connector to the EVR solenoid.
7. Connect the negative battery cable.

### EGR Valve

#### 3.8L ENGINE

1. Disconnect the negative battery cable.
2. Detach the vacuum line(s) and/or electrical connector(s) from the EGR valve.
3. Remove the mounting bolts, then remove the EGR valve. Remove all old gasket material.

#### To install:


4. Using a new gasket, install the EGR valve, then secure using the retaining bolts.

5. Attach any vacuum lines or electrical connectors disengaged during removal.
6. Connect the negative battery cable.

### 4.6L ENGINE


♦ See Figures 20 thru 27

1. Disconnect the negative battery cable.
2. Remove the vacuum hose from the EGR valve.
3. On the 4.6L engine, remove the nut and the brake booster bracket.
4. Disconnect the EGR valve-to-exhaust manifold tube from the EGR valve.
5. Remove the EGR valve mounting bolts, then separate the valve from the intake manifold.
6. Remove and discard the old EGR valve gas-




91194P32

**Fig. 15 Detach the connector for the EVR solenoid**




91194P33

**Fig. 16 Match mark the vacuum hoses for the EVR solenoid and . . .**




91194P34

**Fig. 17 . . . remove the vacuum hoses from the EVR solenoid**




91194P35

**Fig. 18 Remove the retaining nut for the solenoid and . . .**



91194P36


**Fig. 19 . . . remove the solenoid from the intake manifold**



91194P44

**Fig. 20 Remove the vacuum hose from the EGR valve**

## 4-6 DRIVEABILITY AND EMISSIONS CONTROLS




**Fig. 21** On the 4.6L engine, remove the nut and the brake booster bracket from the EGR mounting stud



**Fig. 22** Using a suitable size wrench, loosen the EGR valve-to-exhaust manifold tube and . . .




**Fig. 23** . . . remove the tube from the EGR valve



**Fig. 24** Remove the EGR valve mounting bolts and . . .



**Fig. 25** . . . remove the EGR valve from the intake manifold



**Fig. 26** Remove the EGR valve gasket and . . .



**Fig. 27** . . . thoroughly clean the EGR valve mounting surface

ket, and clean the gasket mating surfaces on the valve and the intake manifold.

### To install:

7. Install the EGR valve, along with a new gasket, on the intake manifold, then install and tighten the mounting bolts.
8. Connect the EGR valve-to-exhaust manifold tube to the valve, then tighten the tube nut to 25–35 ft. lbs. (34–47 Nm).
9. Connect the vacuum hose to the EGR valve.
10. On the 4.6L engine install the brake booster bracket and the retaining nut.
11. Connect the negative battery cable.

### 5.0L ENGINE

1. Disconnect the negative battery cable.
2. Remove the air cleaner outlet tube.
3. Detach the EVP sensor connector.
4. Disconnect the EGR valve-to-exhaust manifold tube from the EGR valve.
5. Remove the vacuum hose from the EGR valve.

6. Remove the EGR valve mounting bolts, then separate the valve from the intake manifold.

7. Remove and discard the old EGR valve gasket, and clean the gasket mating surfaces on the valve and the intake manifold.

### To install:

➔ **If replacing the EGR valve, transfer the EVP sensor onto the new valve.**

8. Install the EGR valve, along with a new gasket, on the upper intake manifold, then install and tighten the mounting bolts.

9. Connect the EGR valve-to-exhaust manifold tube to the valve, then tighten the tube nut to 25–35 ft. lbs. (34–47 Nm).

10. Connect the vacuum hose to the EGR valve:

11. Attach the EVP sensor connector.
12. Install the air cleaner outlet tube.
13. Connect the negative battery cable.

## ELECTRONIC ENGINE CONTROLS

### Powertrain Control Module (PCM)

#### OPERATION

The Powertrain Control Module (PCM) performs many functions on your vehicle. The module accepts information from various engine sensors and computes the required fuel flow rate

necessary to maintain the correct amount of air/fuel ratio throughout the entire engine operational range.

Based on the information that is received and programmed into the PCM's memory, the PCM generates output signals to control relays, actuators and solenoids. The PCM also sends out a command to the fuel injectors that meters the appropriate quantity of fuel. The module automatically senses and compensates for any changes in altitude when driving your vehicle.

### Oxygen Sensor

#### OPERATION

♦ **See Figure 28**

The oxygen (O<sub>2</sub>) sensor is a device that produces an electrical voltage when exposed to the oxygen present in the exhaust gases. The sensor is mounted in the exhaust system, usually in the

manifold or a boss located on the down pipe before the catalyst. Most of the oxygen sensors used on the sophisticated systems of today are heated internally for faster reaction when the engine is started cold. The oxygen sensor produces a voltage within zero and one volt. When there is a large amount of oxygen present (lean mixture), the sensor produces a low voltage (less than 0.4v). When there is a lesser amount present (rich mixture) it produces a higher voltage (0.6–1.0v). The stoichiometric or correct air to fuel ratio will fluctuate between 0.4 and 0.6v. By monitoring the oxygen content and converting it to electrical voltage, the sensor acts as a rich-lean switch. The voltage is transmitted to the PCM.

Some models have two or more sensors, before

the catalyst and after. This is done for a catalyst efficiency monitor that is a part of the OBD-II engine controls that are on all models from the 1995 model year on. The sensor before the catalyst measures the exhaust emissions right out of the engine, and sends the signal to the PCM about the state of the mixture as previously talked about. The second sensor reports the difference in the emissions after the exhaust gases have gone through the catalyst. This sensor reports to the PCM the amount of emissions reduction the catalyst is performing.

The oxygen sensor will not work until a predetermined temperature is reached, until this time the PCM is running in OPEN LOOP operation. OPEN LOOP means that the PCM has not yet begun to correct the air-to-fuel ratio by reading the oxygen sensor. After the engine comes to operating temperature, the PCM will monitor the oxygen sensor and correct the air/fuel ratio from the readings of the sensor. This is known as CLOSED LOOP operation.

A heated oxygen sensor (HO2S) has a heating element that keeps the sensor at proper operating temperature during all operating modes. Maintaining correct sensor temperature at all times allows the system to enter CLOSED LOOP operation sooner.

In CLOSED LOOP operation the PCM monitors the sensor input (along with other inputs) and adjusts the injector pulse width accordingly. During OPEN LOOP operation, the PCM ignores the sensor input and adjusts the injector pulse to a preprogrammed value based on other inputs.

## TESTING

▶ See Figure 29

### \*\*\* WARNING

**Do not pierce the wires when testing this sensor; this can lead to wiring harness damage. Backprobe the connector to properly read the voltage of the HO2S.**

1. Warm the engine to normal operating temperature.
2. Turn the engine OFF. Disconnect the HO2S.
3. Connect a voltmeter, and engine running, measure the voltage on the DC scale between terminals HO2S and SIG RTN (GND) of the oxygen sensor connector. Voltage should fluctuate between 0.01–1.0 volts. If voltage fluctuation is slow or voltage is not within specification, the sensor may be faulty.

## REMOVAL & INSTALLATION

▶ See Figures 30 thru 36

➔ An oxygen sensor socket/wrench is available from Ford or aftermarket manufacturers to ease the removal and installation of the oxygen sensor(s). If one is not available, an open-end wrench can be used.


### \*\*\* WARNING

**The sensor uses a permanently attached pigtail and connector. This pigtail should**



93144P20

**Fig. 28** This is the location of the HO2 sensor on the 3.8L Continental—easily accessible




91054P13

**Fig. 29** The HO2S can be monitored with an appropriate and Data-stream capable scan tool




91194P20

**Fig. 30** Detach the connector for the HO2S sensor




91194P23

**Fig. 31** A special socket is available to remove the HO2S sensor that contains a slot for the wire harness to slide out of




91194P22

**Fig. 32** Place the socket onto the sensor and . . .



91194P21


**Fig. 33** Loosen the sensor using a suitable drive tool



91194P25

**Fig. 34** After the sensor is sufficiently loose using the drive tool, remove the sensor from the exhaust pipe by hand





91194P25

**Fig. 35** Inspect the sensor tip for any signs of build-up or damage



93144P19

**Fig. 36** Coat the threads of the sensor with a suitable anti-seize compound before installation

not be removed from the sensor. Damage or removal of the pigtail or connector will affect the proper operation of the sensor. Keep the electrical connector and lowered end of the sensor clean and free of grease. NEVER use cleaning solvents of any type on the sensor! The oxygen sensor may be difficult to remove when the temperature of the engine is below 120°F (49°C). Excessive force may damage the threads in the exhaust manifold or exhaust pipe.

1. Disconnect the negative battery cable.
2. Raise and support the vehicle.
3. Unplug the electrical connector and any attaching hardware.

➔ Lubricate the sensor with penetrating oil before removal.

4. Remove the sensor using an appropriate tool. Special oxygen sensor sockets are available to remove the sensor and can be purchased at many parts stores or where automotive tools are sold. The proper size wrench can be used, most sensors are 7/8 inch or 22mm sizes.

5. A 22mm crows foot works very well.

**To install:**

6. Coat the threads of the sensor with a suitable anti-seize compound before installation. New sensors are treated with this compound.

7. Install the sensor and tighten it. Use care in making sure the silicone boot is in the correct position to avoid melting it during operation.

8. Attach the electrical connector.
9. Lower the vehicle.
10. Connect the negative battery cable.

## Idle Air Control Valve

### OPERATION

The Idle Air Control (IAC) valve adjusts the engine idle speed. The valve is located on the throttle body. The valve is controlled by a duty cycle signal from the PCM and allows air to bypass the throttle plate in order to maintain the proper idle speed.

### TESTING

➔ See Figure 37

1. Turn the ignition switch to the OFF position.
2. Disconnect the wiring harness from the IAC valve.
3. Measure the resistance between the terminals of the valve.

➔ Due to the diode in the solenoid, place the ohmmeter positive lead on the VPWR terminal and the negative lead on the ISC terminal.

4. Resistance should be 7–13 ohms.
5. If resistance is not within specification, the valve may be faulty.



91054P12


**Fig. 37** The IAC can be monitored with an appropriate and Data-stream capable scan tool

### REMOVAL & INSTALLATION

➔ See Figures 38 and 39


1. Disconnect the negative battery cable.
2. Detach the IAC solenoid connector.
3. Remove the two retaining bolts and remove the IAC solenoid and gasket from the throttle body.
4. Installation is the reverse of the removal procedure. Use a new gasket and tighten the retaining bolts to 71–97 inch lbs. (8–11 Nm).

➔ If scraping is necessary to remove old gasket material, be careful not to damage the IAC solenoid or the throttle body gasket surfaces or drop material into the throttle body.



04174028

**Fig. 38** IAC solenoid location—4.6L engine



93143P08

**Fig. 39** This is an IAC valve off of a 5.0L engine

## Engine Coolant Temperature (ECT) Sensor

### OPERATION


The Engine Coolant Temperature (ECT) sensor resistance changes in response to engine coolant temperature. The sensor resistance decreases as the coolant temperature increases, and increases as the coolant temperature decreases. This provides a reference signal to the PCM, which indicates engine coolant temperature. The signal sent to the PCM by the ECT sensor helps the PCM to determine spark advance, EGR flow rate, air/fuel ratio, and engine temperature. The ECT is a two-wire sensor, a 5-volt reference signal is sent to the sensor and the signal return is based upon the change in the measured resistance due to temperature.

### TESTING

➔ See Figures 40, 41 and 42

1. Disconnect the engine wiring harness from the ECT sensor.
2. Connect an ohmmeter between the ECT sensor terminals.






TCCS4P02

**Fig. 40** Another method of testing the ECT is to submerge it in cold or hot water and check resistance

Temperature		Engine Coolant/Intake Air Temperature Sensor Values
°F	°C	Resistance (K ohms)
248	120	1.18
230	110	1.55
212	100	2.07
194	90	2.80
176	80	3.84
158	70	5.37
140	60	7.70
122	50	10.97
104	40	16.15
86	30	24.27
68	20	37.30
50	10	58.75

89694623

**Fig. 41** ECT resistance-to-temperature specifications



91194P14

**Fig. 42** Test the ECT resistance across the two sensor terminals

3. With the engine cold and the ignition switch in the **OFF** position, measure and note the ECT sensor resistance.

4. Connect the engine wiring harness to the sensor.

5. Start the engine and allow the engine to reach normal operating temperature.

6. Once the engine has reached normal operating temperature, turn the engine **OFF**.

7. Again, disconnect the engine wiring harness from the ECT sensor.

8. Measure and note the ECT sensor resistance with the engine hot.

9. Compare the cold and hot ECT sensor resistance measurements with the accompanying chart.

10. If readings do not approximate those in the chart, the sensor may be faulty.

## REMOVAL & INSTALLATION

### ▶ See Figures 43 thru 48

1. Disconnect the negative battery cable.
2. Drain and recycle the engine coolant.

### \*\*\* CAUTION

Never open, service, or drain the radiator or cooling system when hot; serious burns can occur from the steam and hot coolant. In addition, when draining engine coolant, keep in mind that cats and dogs are attracted to ethylene glycol antifreeze and could drink any that is left in an uncovered container or in puddles on the ground. This



89604P21

**Fig. 43** Detach the connector for the ECT sensor and . . .




89604P22

**Fig. 44** . . . and loosen the sensor using a suitable socket or other drive tool



89604P23

**Fig. 45** Once the sensor is sufficiently loose, remove the sensor from the intake manifold by hand




91054P36

**Fig. 46** Use a quality thread sealant to . . .



91054P37

**Fig. 47** . . . coat the threads of the ECT sensor before installation



89604P24

**Fig. 48** The ECT sensor must be tightened with a torque wrench to specifications

# 4-10 DRIVEABILITY AND EMISSIONS CONTROLS

will prove fatal in sufficient quantities. Always drain coolant into a sealable container. Coolant should be reused unless it is contaminated or is several years old.

3. Remove the air cleaner outlet tube if necessary.
4. Detach the ECT sensor connector.
5. Remove the ECT sensor from the intake manifold.

**To install:**


6. Coat the sensor threads with Teflon® sealant.
7. Thread the sensor into position and tighten to 6–8 ft. lbs. (8–13 Nm).
8. Attach the ECT sensor connector.
9. Install the air cleaner outlet tube.
10. Connect the negative battery cable.
11. Refill the engine cooling system.
12. Start the engine and check for coolant leaks.
13. Bleed the cooling system.

## Intake Air Temperature Sensor

### OPERATION

▶ See Figure 49

The Intake Air Temperature (IAT) sensor determines the air temperature inside the intake manifold. Resistance changes in response to the ambient air temperature. The sensor has a negative temperature coefficient. As the temperature of the sensor rises the resistance across the sensor decreases. This



**Fig. 49** The tip of the IAT sensor has an exposed thermistor that changes the resistance of the sensor based upon the force of the air rushing past it

provides a signal to the PCM indicating the temperature of the incoming air charge. This sensor helps the PCM to determine spark timing and air/fuel ratio. Information from this sensor is added to the pressure sensor information to calculate the air mass being sent to the cylinders. The IAT is a two-wire sensor, a 5-volt reference signal is sent to the sensor and the signal return is based upon the change in the measured resistance due to temperature.

### TESTING

▶ See Figures 50 and 51

1. Turn the ignition switch OFF.
2. Disconnect the wiring harness from the IAT sensor.
3. Measure the resistance between the sensor terminals.
4. Compare the resistance reading with the accompanying chart.
5. If the resistance is not within specification, the IAT may be faulty.
6. Connect the wiring harness to the sensor.

### REMOVAL & INSTALLATION

#### 1988–95 Models

1. Disconnect the negative battery cable.
2. Detach the electrical connector from the IAT sensor.
3. Using a suitable socket and drive tool, remove the IAT sensor from the air inlet.



**Fig. 50** The IAT sensor can be monitored with an appropriate and Data-stream capable scan tool

4. On the 5.0L engine Lincoln models, the IAT sensor is located in the intake manifold

**To install:**

5. Coat the sensor threads with Teflon® sealant.
6. Thread the sensor into position and tighten it to 6–8 ft. lbs. (8–13 Nm).
7. Attach the electrical connector to the IAT sensor.
8. Connect the negative battery cable.

#### 1996–00 Models

1. Disconnect the negative battery cable.
2. Detach the electrical connector from the IAT sensor.
3. Turn the sensor 90° counterclockwise and remove the IAT sensor from the air cleaner lid.
4. Remove the sensor O-ring and inspect it.

Replace as necessary.

**To install:**

5. The installation is the reverse of the removal.

## Mass Airflow Sensor

### OPERATION


▶ See Figure 52

The Mass Air Flow (MAF) sensor directly measures the mass of air being drawn into the engine. The sensor output is used to calculate injector pulse width. The MAF sensor is what is referred to as a "hot-wire sensor". The sensor uses a thin platinum wire filament, wound on a ceramic bobbin and coated with glass, that is heated to 200°C (417°F) above the ambient air temperature and subjected to the intake airflow stream. A "cold-wire" is used inside the MAF sensor to determine the ambient air temperature.

Battery voltage from the EEC power relay, and a reference signal and a ground signal from the PCM are supplied to the MAF sensor. The sensor returns a signal proportionate to the current flow required keeping the "hot-wire" at the required temperature. The increased airflow across the "hot-wire" acts as a cooling fan, lowering the resistance and requiring more current to maintain the temperature of the wire. The voltage in the circuit measures the increased current. As current increases, voltage increases. As the airflow increases the signal return voltage of a normally operating MAF sensor will increase.

Temperature		Engine Coolant/Intake Air Temperature Sensor Values
°F	°C	Resistance (K ohms)
248	120	1.18
230	110	1.55
212	100	2.07
194	90	2.80
176	80	3.84
158	70	5.37
140	60	7.70
122	50	10.97
104	40	18.15
86	30	24.27
68	20	37.30
50	10	58.75

**Fig. 51** IAT resistance-to-temperature specifications



**Fig. 52** The exposed "hot wire" of the MAF sensor

## TESTING

### See Figure 53

1. Using a multimeter, check for voltage by backprobing the MAF sensor connector.
2. With the key **ON**, and the engine **OFF**, verify that there is at least 10.5 volts between the VPWR and GND terminals of the MAF sensor connector. If voltage is not within specification, check power and ground circuits and repair as necessary.
3. With the key **ON**, and the engine **ON**, verify that there is at least 4.5 volts between the SIG and GND terminals of the MAF sensor connector. If voltage is not within specification, check power and ground circuits and repair as necessary.
4. With the key **ON**, and the engine **ON**, check voltage between GND and SIG RTN terminals. Voltage should be approximately 0.34–1.96 volts. If voltage is not within specification, the sensor may be faulty.



**Fig. 53 Unplugging the sensor connector below the MAF sensor, for testing purposes**

## REMOVAL & INSTALLATION

1. Disconnect the negative battery cable.
  2. Remove the air intake tube from the MAF sensor and the throttle body.
  3. Detach the connector from the MAF sensor.
  4. Remove the four sensor retaining screws and remove the sensor.
  5. Remove the sensor gasket.
- To install:**
6. Installation is the reverse of removal.

## Manifold Air Pressure (MAP) Sensor


## OPERATION

The most important information for measuring engine fuel requirements comes from the pressure sensor. Using the pressure and temperature data, the PCM calculates the intake air mass. It is connected to the engine intake manifold through a hose and takes readings of the absolute pressure. A piezoelectric crystal changes a voltage input to a frequency output, which reflects the pressure in the intake manifold.

Atmospheric pressure is measured when the engine is started and when driving fully loaded,

then the pressure sensor information is adjusted accordingly.

The Manifold Absolute Pressure (MAP) sensor was used on the 3.8L & the 5.0L engines, until it was replaced by the Mass Air Flow (MAF). The MAP sensor operates as a pressure-sensing disc. It does not generate a voltage; instead its output is a frequency change. The sensor changes frequency according to intake manifold vacuum; as vacuum increases sensor frequency increases. This gives the Powertrain Control Module (PCM) information on engine load. The PCM uses the MAP sensor signal to help determine spark advance, EGR flow and air/fuel ratio.



**Fig. 54 Manifold Absolute Pressure Sensor**

## TESTING

### See Figures 54, 55 and 56

⇒ **Unusually high or low barometric pressures can generate a false DTC for the MAP sensor. If no driveability symptoms accompany the MAP code, do not replace it.**

1. Connect a MAP/BARO tester to the sensor connector and sensor harness connector. With ignition **ON** and engine **OFF**, use DVOM to measure voltage across tester terminals. If the tester's 4-6V indicator is ON, the reference voltage input to the sensor is okay.

⇒ **The green light on the tester indicates that the VREF circuit is okay, 4–6 volts. A red light or no light indicates the VREF is either too low or too high.**


Approximate Altitude (Ft.)	Voltage Output (±.04 Volts)
0	1.59
1000	1.56
2000	1.53
3000	1.50
4000	1.47
5000	1.44
6000	1.41
7000	1.39

84174023

**Fig. 55 MAP sensor altitude/voltage output relationship**

### MAP Sensor Graph

**NOTE:** MAP sensor output frequency versus manifold vacuum data is based on 30.0 in-Hg barometric pressure.



### MAP Sensor Data

Manifold Vacuum		Frequency
in-Hg	kPa	Hz
0	0	159
3	10.2	150
6	20.3	141
9	30.5	133
12	40.6	125
15	50.8	117
18	61.0	109
21	71.1	102
24	81.3	95
27	91.5	88
30	101.6	80

**Fig. 56 MAP sensor frequency data**

# 4-12 DRIVEABILITY AND EMISSIONS CONTROLS

2. Measure the reference signal of the MAP sensor. If the DVOM voltage reading is as indicated in the table, the sensor is okay.
  - a. Turn the ignition **OFF**.
  - b. Disconnect the vacuum hose from the MAP sensor and connect a vacuum pump in its place.
  - c. Apply 18 in. Hg of vacuum to the MAP sensor.
  - d. If the MAP sensor holds vacuum, it is okay. If the MAP sensor does not hold vacuum, it must be replaced.

## REMOVAL & INSTALLATION

1. Disconnect the negative battery cable.
2. Detach the electrical connector and the vacuum line from the sensor.
3. Remove the sensor mounting bolts and remove the sensor.
4. Installation is the reverse of the removal procedure.

## Throttle Position Sensor

### OPERATION

The Throttle Position (TP) sensor is a potentiometer that provides a signal to the PCM that is directly proportional to the throttle plates position. The TP sensor is mounted on the side of the throttle body and is connected to the throttle plate shaft. The TP sensor monitors the throttle plate's movement and position, and transmits an appropriate electrical signal to the PCM. The PCM uses these signals to adjust the air/fuel mixture, spark timing, and EGR operation according to engine load at idle, part throttle, or full throttle. The TP sensor is not adjustable.

The TP sensor receives a 5-volt reference signal and a ground circuit from the PCM. A return signal circuit connects to a wiper that runs on a resistor internally in the sensor. The more the throttle opens the further the wiper moves along the resistor. At wide open throttle, the wiper essentially creates a loop between the reference signal and the signal return, returning the full, or nearly full 5 volt signal back to the PCM. At idle the signal return should be approximately 0.9 volts.

### TESTING

#### ♦ See Figures 57, 58, 59 and 60

1. With the engine **OFF** and the ignition **ON**, check the voltage at the signal return circuit of the TP sensor by carefully backprobing the connector using a DVOM.
2. Voltage should be between 0.2 and 1.4 volts at idle.
3. Slowly move the throttle pulley to the wide-open throttle (WOT) position and watch the voltage on the DVOM. The voltage should slowly rise to slightly less than 4.8v at Wide Open Throttle (WOT).
4. If no voltage is present, check the wiring harness for supply voltage (5.0v) and ground (0.3v or less), by referring to your corresponding wiring guide. If supply voltage and ground are present, but



**Fig. 57 Testing the TP sensor signal return voltage at idle**



**Fig. 58 Test the operation of the TP sensor by gently opening the throttle while observing the signal return voltage. The voltage should move smoothly according to the amount the throttle is opened**



**Fig. 59 Testing the supply voltage at the TP sensor connector**



**Fig. 60 The TP sensor can be monitored with an appropriate and Data-stream capable scan tool**

no output voltage from TP, replace the TP sensor. If supply voltage and ground do not meet specifications, make necessary repairs to the harness or PCM.

## REMOVAL & INSTALLATION

1. Disconnect the negative battery cable.  
⇒ On a 4.6L engine, it may be necessary to remove the throttle cover from the engine.
2. Disconnect the wiring harness from the TP sensor.
3. Remove the two sensor mounting screws, then pull the TP sensor off of the throttle shaft.  
**To install:**
4. Carefully slide the rotary tangs on the sensor into position over the throttle shaft, then rotate the sensor clockwise to the installed position..

### \*\*\* CAUTION

**Failure to install the TP sensor in this manner may result in sensor damage or high idle speeds.**

⇒ The TP sensor is not adjustable.

5. Install and tighten the sensor mounting screws to 27 inch lbs. (3 Nm).
6. Connect the wiring harness to the sensor.
7. If removed, install the throttle cover.
8. Connect the negative battery cable.

## Camshaft Position Sensor

⇒ The Camshaft Position Sensor (CMP) is only outfitted on the 4.6L engine.

The camshaft position sensor (CMP) is a variable reluctance sensor that is triggered by a high point on the left-hand exhaust camshaft sprocket. The CMP sends a signal relating camshaft position back to the PCM and that signal is used by the PCM to check engine timing.

### TESTING

1. Check voltage between the camshaft position sensor terminals PWR GND and CID.
2. With engine running, voltage should be greater than 0.1 volt AC and vary with engine speed.
3. If voltage is not within specification, check for proper voltage at the VPWR terminal.
4. If VPWR voltage is greater than 10.5 volts, sensor may be faulty.


## REMOVAL & INSTALLATION

### 4.6L Engine

♦ See Figures 61, 62 and 63


1. Disconnect the negative battery cable.
2. Detach the electrical connector for the CMP sensor.
3. Remove the CMP sensor retaining bolt(s) and remove the CMP sensor from the front cover.  
**To install:**
4. Installation is the reverse of removal.





91194P57

**Fig. 61 Detach the connector for the CMP sensor and . . .**



91194P58

**Fig. 62 . . . remove the bolt retaining the CMP sensor to the front cover and . . .**



91194P59

**Fig. 63 . . . remove the sensor**

## Crankshaft Position Sensor

### OPERATION

▶ See Figure 64

The Crankshaft Position (CKP) sensor is a variable reluctance sensor that uses a trigger wheel to induce voltage. The CKP sensor is a fixed magnetic sensor mounted to the engine block and monitors the trigger or "pulse" wheel that is attached to the crank pulley/damper. As the pulse wheel rotates by the CKP sensor, teeth on the pulse wheel induce voltage inside the sensor through magnetism. The pulse wheel has a missing tooth that changes the reading of the sensor. This is used for the Cylinder Identification (CID) function to properly monitor and adjust engine timing by locating the number 1 cylinder.

der. The voltage created by the CKP sensor is alternating current (A/C). This voltage reading is sent to the PCM, it is used to determine engine RPM, engine timing, and is used to fire the ignition coils.

### TESTING

1. Measure the voltage between the sensor CKP sensor terminals by backprobing the sensor connector.

➡ **If the connector cannot be backprobed, fabricate or purchase a test harness.**

2. Sensor voltage should be more than 0.1 volt AC with the engine running and should vary with engine RPM.

3. If voltage is not within specification, the sensor may be faulty.


### REMOVAL & INSTALLATION

▶ See Figure 65


1. Disconnect the negative battery cable.
2. Remove the accessory drive belt from the engine.
3. Raise and safely support the vehicle.
4. Remove the A/C compressor mounting bolts, but do not disconnect the A/C lines. Remove and support the compressor out of the way.
5. Detach the electrical connector for the CKP sensor.
6. Remove the CKP sensor retaining bolts and remove the CKP sensor.

**To install:**

7. Installation is the reverse of removal.



**Fig. 64 The CKP sensor trigger wheel rides on the front of the crankshaft. The missing tooth creates a fluctuation of voltage in the sensor**




**Fig. 65 Remove the retaining bolt for the CKP sensor and remove the sensor from the front cover**

## COMPONENT LOCATIONS

### COMMON EMISSIONS AND ELECTRONIC ENGINE CONTROL COMPONENT LOCATIONS—3.8L ENGINE


1. VECI decal
2. ICRM control (under sight shield)
3. Fuel pressure regulator
4. ECT (Engine Coolant Temperature) sensor
5. EGR (Exhaust Gas Recirculation) valve
6. PFE (Pressure Feedback Exhaust) sensor
7. MAF (Mass Air Flow) sensor
8. TP (Throttle Position) sensor
9. IAC (Idle Air Control) valve
10. Fuel injector (6 total)
11. Scan tool (VIP test) connector
12. TFI (Ignition) module






**COMMON EMISSIONS AND ELECTRONIC ENGINE CONTROL COMPONENT LOCATIONS—4.6L ENGINE**

- 1. Fuel pressure regulator
- 2. ECT (Engine Coolant Temperature) sensor
- 3. EGR (Exhaust Gas Recirculation) valve
- 4. DPFE (Delta Pressure Feedback Exhaust) sensor
- 5. MAF (Mass Air Flow) sensor
- 6. TP (Throttle Position) sensor
- 7. IAC (Idle Air Control) valve
- 8. Fuel injector (8 total)
- 9. Scan tool (VIP test) connector
- 10. EDIS (Electronic Distributorless Ignition) module
- 11. Anti-lock brake test connector



## COMMON EMISSIONS AND ELECTRONIC ENGINE CONTROL COMPONENT LOCATIONS—5.0L ENGINE

- |  |                                       |
|--|---------------------------------------|
| 1. VECI decal                              | 7. IAC (Idle Air Control) valve       |
| 2. Fuel pressure regulator                 | 8. Fuel injectors (8 total)           |
| 3. ECT (Engine Coolant Temperature) sensor | 9. Scan tool (VIP test) connector     |
| 4. EGR (Exhaust Gas Recirculation) valve   | 10. TFI (Ignition) module             |
| 5. EVP (Electronic Valve Position) sensor  | 11. Thermoacoustic pump               |
| 6. TP (Throttle Position) sensor           | 12. EVR (Electronic Vacuum Regulator) |





## TROUBLE CODES —EEC-IV SYSTEM

### General Information

The Powertrain Control Module (PCM) is devoted to monitoring both input and output functions within the system. This ability forms the core of the self-diagnostic system. If a problem is detected within a circuit, the controller will recognize the fault, assign it an identification code, and store the code in a memory section. Depending on the year and model, the fault code(s) may be represented by two or three-digit numbers. The stored code(s) may be retrieved during diagnosis.

While the EEC-IV system is capable of recognizing many internal faults, certain faults will not be recognized. Because the computer system sees only electrical signals, it cannot sense or react to mechanical or vacuum faults affecting engine operation. Some of these faults may affect another component which will set a code. For example, the PCM monitors the output signal to the fuel injectors, but cannot detect a partially clogged injector. As long as the output driver responds correctly, the computer will read the system as functioning correctly. However, the improper flow of fuel may result in a lean mixture. This would, in turn, be detected by the oxygen sensor and noticed as a constantly lean signal by the PCM. Once the signal falls outside the pre-programmed limits, the engine control assembly would notice the fault and set an identification code.

### FAILURE MODE EFFECTS MANAGEMENT (FMEM)

The PCM contains back-up programs that allow the engine to operate if a sensor signal is lost. If sensor input is seen to be out of range—either high or low—the FMEM program is used. The processor substitutes a fixed value for the missing sensor signal. The engine will continue to operate, although performance and driveability may be noticeably reduced. This function of the controller is sometimes referred to as the limp-in or fail-safe mode. If the missing sensor signal is restored, the FMEM system immediately returns the system to normal operation. The dashboard-warning lamp will be lit when FMEM is in effect.

### HARDWARE LIMITED OPERATION STRATEGY (HLOS)

This mode is only used if the fault is too extreme for the FMEM circuit to handle. In this mode, the processor has ceased all computation and control; the entire system is run on fixed values. The vehicle may be operated but performance and driveability will be greatly reduced. The fixed or default settings provide minimal calibration, allowing the vehicle to be carefully driven in for service. The dashboard-warning lamp will be lit when HLOS is engaged. Codes cannot be read while the system is operating in this mode.

### Diagnostic Link Connector

With the advent of OBD-II, the Federal Government has mandated the location of the DLC (Data Link Connector). The Data Link Connector is

located in the passenger compartment. It is attached to the instrument panel and accessible from the driver's seat.

The DLC is rectangular in design and capable of allowing access to 16 terminals. The connector has keying features that allow easy connection. The test equipment and the DLC have a latching feature to ensure a good mated connection. The Scan tool uses the DLC as a pathway to communicate with the on board computer system.

If the DLC is not located under the dash, the vehicle is using OBD-I. This is a slightly different management system in its operation and diagnosis. Look for DLC under the hood near the left front headlight on the Town Car and Mark VII, near the right side firewall on the Continental.

### HAND-HELD SCAN TOOLS

▶ See Figures 66, 67, 68 and 69

Although stored codes may be read through the flashing of the CHECK ENGINE or SERVICE ENGINE SOON lamp, the use of hand-held scan tools such as Ford's Self-Test Automatic Readout (STAR) tester or the second generation SUPER STAR II tester or their equivalent is highly recommended. There are many manufacturers of these tools; the purchaser must be certain that the tool is proper for the intended use.

The scan tool allows any stored faults to be read from the engine controller memory. Use of the scan




Fig. 66 Super Star II tester—Ford Motor Co.



Fig. 67 Inexpensive scan tools, such as this Auto Xray®, are available to interface with your Ford vehicle




Fig. 68 An economically friendly alternative is this Code Scanner® from SunPro. They are purchased according to manufacturer and are available at many parts stores



Fig. 69 The Code Scanner® from SunPro has no LCD display, just a LED that will flash out the codes and an audible buzzer to alert that the test is in progress

tool provides additional data during troubleshooting, but does not eliminate the use of the charts. The scan tool makes collecting information easier, but an operator familiar with the system must correctly interpret the data.

### ELECTRICAL TOOLS

The most commonly required electrical diagnostic tool is the digital multimeter; also known as a Digital Volt Ohmmeter (DVOM), which permits voltage, resistance (ohms) and amperage to be read by one instrument.

The multimeter must be a high impedance unit, with 10 megaohms of impedance in the voltmeter. This type of meter will not place an additional load on the circuit it is testing; this is extremely important in low voltage circuits. The multimeter must be of high quality in all respects. It should be handled carefully and protected from impact or damage. Replace the batteries frequently in the unit.

Additionally, an analog (needle type) voltmeter may be used to read stored fault codes if the STAR tester is not available. The codes are transmitted as visible needle sweeps on the face of the instrument.

Nearly all the diagnostic procedures will require

# 4-18 DRIVEABILITY AND EMISSIONS CONTROLS

the use of a Breakout Box, a device that connects into the EEC-IV harness and provides testing ports for the 60 wires in the harness. Direct testing of the harness connectors at the terminals or by backprobing is not recommended; damage to the wiring and terminals are almost certain to occur.

Other necessary tools include a quality tachometer with inductive (clip-on) pickup, a fuel pressure gauge with system adapters and a vacuum gauge with an auxiliary source of vacuum.

## Reading Codes

Diagnosis of a driveability problem requires attention to detail and following the diagnostic procedures in the correct order. Resist the temptation to begin extensive testing before completing the preliminary diagnostic steps. The preliminary or visual inspection must be completed in detail before diagnosis begins. In many cases this will shorten diagnostic time and often cure the problem without electronic testing.

## VISUAL INSPECTION

This is possibly the most critical step of diagnosis. A detailed examination of all connectors, wiring and vacuum hoses can often lead to a repair without further diagnosis. Performance of this step relies on the skill of the technician performing it; a careful inspector will check the undersides of hoses as well as the integrity of hard-to-reach hoses blocked by the air cleaner or other components. Wiring should be checked carefully for any sign of strain, burning, crimping or terminal pull-out from a connector.

Checking connectors at components or in harnesses is required; usually, pushing them together will reveal a loose fit. Pay particular attention to ground circuits, making sure they are not loose or corroded. Remember to inspect connectors and hose fittings at components not mounted on the engine, such as the evaporative canister or relays mounted on the fender aprons. Any component or wiring near a fluid leak or

spillage should be given extra attention during inspection.

Additionally, inspect maintenance items such as belt condition and tension, battery charge and condition and the radiator cap carefully. Any of these very simple items may affect the system enough to set a fault.

## ELECTRONIC TESTING

If a code was set before a problem self-corrected (such as a momentarily loose connector), the code will be erased if the problem does not reoccur within 80 warm-up cycles. Codes will be output and displayed as numbers on the handheld scan tool, such as 23. If the codes are being read on an analog voltmeter, the needle sweeps indicate the code digits. code 23 will appear as two needle pulses (sweeps) then, after a 1.6 second pause, the needle will pulse (sweep) three times.

Service Codes	Quick Test Mode
11—System pass	O/R/C
12—Rpm unable to reach upper test limit	R
13—DC motor movement not detected	O
13—Rpm unable to achieve lower test limit	R
13—DC motor did follow dashpot	C
14—PIP circuit failure	C
15—ECA read only memory test failed	O
15—ECA keep alive memory test failed	C
16—Idle rpm high with ISC off	R
16—Idle too low to perform EGO test	R
17—Idle rpm low with ISC off	R
18—SPOUT circuit open or spark angle word failure	R
18—IDM circuit failure or SPOUT circuit grounded	C
19—Failure in ECA internal voltage	O
19—CID circuit failure	C
19—Rpm dropped too low in ISC off test	R
19—Rpm for EGR test not achieved	R
21—ECT out of self-test range	O/R
22—BP sensor out of self-test range	O/R
22—BP or MAP out of self-test range	O/R/C
23—TP out of self-test range	O/R
23—TP out of self-test range	O/R/C
24—ACT sensor out of self-test range	O/R
25—Knock not sensed during dynamic test	R
26—VAF/MAF out of self-test range	O/R
28—VAT out of self-test range	C
29—Insufficient input from vehicle speed sensor	O/R/C
31—PFE, EVP or EVR circuit below minimum voltage	R/C
32—EPT circuit voltage low (PFE)	O/R/C
32—EVP voltage below closed limit	R
32—EGR not controlling	R/C
33—EGR valve opening not detected	R
33—EGR not closing fully	O
34—Defective PFE sensor or voltage out of range	R/C
34—EPT sensor voltage high (PFE)	O/R/C
34—EVP voltage above closed limit	R
34—EGR opening not detected	O/R/C
35—PFE or EVP circuit above maximum voltage	R
35—Rpm too low to perform EGR test	C
38—Idle tracking switch circuit open	C
39—AXOD lock up failed	R
41—HEGO sensor circuit indicates system lean	R
41—No HEGO switching detected	R
42—HEGO sensor circuit indicates system rich	C
42—No HEGO switching detected—reads rich	C
43—HEGO lean at wide open throttle	R
44—Thermactor air system inoperative—ride side	R
45—Thermactor air upstream during self-test	C
45—Coil 1 primary circuit failure	R
46—Thermactor air not bypassed during self-test	C
46—Coil 2 primary circuit failure	R
47—Measured airflow low at base idle	C
48—Coil 3 primary circuit failure	R
48—Measured airflow high at base idle	C
49—SPOUT signal defaulted to 10°BTDC or SPOUT open	O/C
51—ECT/ACT reads -40°F or circuit open	O
52—Power steering pressure switch circuit open	R
52—Power steering pressure switch always open or closed	R

93144G04

Service Codes	Quick Test Mode
53—TP circuit above maximum voltage	O/C
54—ACT sensor circuit open	O/C
55—Keypower circuit open	R
56—VAF or MAF circuit above maximum voltage	O/C
56—MAF circuit above maximum voltage	O/R/C
57—Octane adjust service pin in use	O
57—AXOD neutral pressure switch circuit failed open	C
58—Idle tracking switch circuit open	O
58—Idle tracking switch closed/circuit grounded	R
58—VAT reads -40°F or circuit open	O/C
59—Idle adjust service pin in use	O
59—AXOD 4/3 pressure switch circuit failed open	C
59—Low speed fuel pump circuit open—Battery to ECA	O/C
59—AXOD 4/3 pressure switch failed closed	O
61—ECT reads 254°F or circuit grounded	O/C
62—AXOD 4/3 or 3/2 pressure switch circuit grounded	O
63—TP circuit below minimum voltage	O/C
64—ACT sensor input below test minimum or grounded	O/C
65—Never went to closed loop fuel control	C
66—MAF sensor input below minimum voltage	C
66—VAF sensor below minimum voltage	O/C
66—MAF circuit below minimum voltage	R/C
67—Neutral/drive switch open or A/C on	O
67—Clutch switch circuit failure	C
67—Neutral/drive switch open or A/C on	O/R
68—Idle tracking switch closed or circuit grounded	O
68—Idle tracking switch circuit open	R
68—AXOD transmission temperature switch failed open	O/R/C
68—VAT reads 254°F or circuit grounded	O/C
69—AXOD 3/2 pressure switch circuit failed closed	O
69—AXOD 3/4 pressure switch circuit failed open	C
70—ECA DATA communications link circuit failure	C
71—Software re-initialization detected	C
71—Idle tracking switch shorted to ground	C
71—Cluster control assembly circuit failed	C
72—Insufficient MAF/MAP change during dynamic test	R
72—Power interrupt or re-initialization detected	C
72—Message center control assembly circuit failed	O
73—Insufficient throttle position change	C
73—Insufficient TP change during dynamic test	R
74—Brake on/off switch failure or not actuated	R
75—Brake on/off switch circuit closed or ECA input open	R
76—Insufficient VAF change during dynamic test	R
77—No WOT seen in self-test or operator error	R
79—A/C or defrost on during self-test	O

93144G05

Service Codes	Quick Test Mode
81—IAS circuit failure	0
81—Air management 2 circuit failure	0
82—Air management 1 circuit failure	0
82—Supercharger bypass circuit failure	0
83—High speed electro drive fan circuit failure	0
83—Low speed fuel pump circuit failure	0/C
84—EGR vacuum solenoid circuit failure	0
84—EGR vacuum regulator circuit failure	0/R
85—Canister purge circuit failure	0/R
85—Canister purge solenoid circuit failure	0
85—Adaptive fuel lean limit reached	C
86—3-4 shift solenoid circuit failure	0
86—Adaptive fuel rich limit reached	C
87—Fuel pump primary circuit failure	0
87—Fuel pump primary circuit failure	0/C/R
87—Fuel pump primary circuit failure	0
88—Electro drive fan circuit failure	0
89—Converter clutch override circuit failure	0
89—Lock-up solenoid circuit failure	0
91—HEGO sensor indicates system lean	R
91—No HEGO switching detected	C
92—HEGO sensor indicates system rich	R
93—TP sensor input low at maximum motor travel	0
94—Thermactor air system inoperative-left side	R
95—Fuel pump secondary circuit failure—ECA to ground	0/C
96—Fuel pump secondary circuit failure—Battery to ECA	0/C
96—High speed fuel pump circuit open	0/C
98—Hard fault present	R
99—EEC has not learned to control idle: ignore codes 12 & 13	R

No Codes: Cannot begin self-test or cannot transmit codes  
 Codes Not Listed: Do not apply to vehicle being tested  
 0—Key on, engine off test  
 R—Key on, engine running test  
 C—Continuous memory  
 ⊕ Front HEGO  
 ⊙ Right HEGO  
 ⊖ Left HEGO  
 ⊗ Rear HEGO

93144G06

**EEC-IV trouble codes —(3 of 3)**

**Key On Engine Off (KOEO) Test**

▶ See Figures 70 thru 76

1. Connect the scan tool to the self-test connectors. Make certain the test button is unlatched or up.
2. Start the engine and run it until normal operating temperature is reached.
3. Turn the engine **OFF** for 10 seconds.
4. Activate the test button on the STAR tester.
5. Turn the ignition switch **ON** but do not start the engine.
6. The KOEO codes will be transmitted. Six to nine seconds after the last KOEO code, a single separator pulse will be transmitted. Six to nine seconds after this pulse, the codes from the Continuous Memory will be transmitted.
7. Record all service codes displayed. Do not depress the throttle on gasoline engines during the test.

**Key On Engine Running (KOER) Test**

▶ See Figures 66, 75, and 77


84924042

1. Make certain the self-test button is released or de-activated on the STAR tester.
2. Start the engine and run it at 2000 rpm for two minutes. This action warms up the oxygen sensor.
3. Turn the ignition switch **OFF** for 10 seconds.
4. Activate or latch the self-test button on the scan tool.
5. Start the engine. The engine identification



91054P04

**Fig. 70** Connect the scan tool to the DLC connector



91054P05

**Fig. 71** The scan tool menu will be displayed, follow the instructions included with the scan tool



91054P08

**Fig. 72** This PCM had no DTC's stored and passed the KOEO




91054P06

**Fig. 73** This PCM had a DTC 113 stored. Most scan tools will give a code definition on-screen as the Auto X-ray shown here informs what code 113 is for—the IAT sensor





91054P07

**Fig. 74** If the A/C or Blower motor is left on, a code 539 will be tripped. Turn the A/C or blower motor off and retest



84924040

**Fig. 75** STAR tester displays; note that the colon must be present before codes can be received



code will be transmitted. This is a single digit number representing 1/2 the number of cylinders in a gasoline engine. On the STAR tester, this number may appear with a zero, such as 20 = 2. The code is used to confirm that the correct processor is installed and that the self-test has begun.

6. If the vehicle is equipped with a Brake On/Off (BOO) switch, the brake pedal must be depressed and released after the ID code is transmitted.

7. If the vehicle is equipped with a Power Steering Pressure Switch (PSPS), the steering wheel must be turned at least 1/2 turn and released within 2 seconds after the engine ID code is transmitted.

8. Certain Ford vehicles will display a Dynamic Response code 6 - 20 seconds after the engine ID code. This will appear as one pulse on a meter or as a 10 on the STAR tester. When this code appears, briefly take the engine to wide-open throttle. This allows the system to test the throttle position, MAF and MAP sensors.

9. All relevant codes will be displayed and should be recorded. Remember that the codes refer only to faults present during this test cycle. Codes stored in Continuous Memory are not displayed in this test mode.


10. Do not depress the throttle during testing unless a dynamic response code is displayed.

### Reading Codes With Analog Voltmeter

See Figures 78 and 79

In the absence of a scan tool, an analog voltmeter may be used to retrieve stored fault codes. Set the meter range to read DC 0 - 15 volts. Connect the + lead of the meter to the battery positive terminal and connect the - lead of the meter to the self-test output pin of the diagnostic connector.

Follow the directions given previously for performing the KOEO and KOER tests. To activate the tests, use a jumper wire to connect the signal return pin on the diagnostic connector to the self-test



input connector. The self-test input line is the separate wire and connector with or near the diagnostic connector.

The codes will be transmitted as groups of needle sweeps. This method may be used to read either 2 or 3-digit codes. The Continuous Memory codes are separated from the KOEO codes by 6 seconds, a single sweep and another 6-second delay.



### Malfunction Indicator Lamp Method

See Figures 80 and 81


The Malfunction Indicator Lamp (MIL) on the dashboard may also be used to retrieve the stored codes. This method displays only the stored codes and does not allow any system investigation. It should only be used in field conditions where a quick check of stored codes is needed.

Follow the directions given previously for performing the scan tool procedure. To activate the tests, use a jumper wire to connect the signal return pin on the diagnostic connector to the Self-Test Input (STI) connector. The self-test input line is the separate wire and connector with or near the diagnostic connector.

Codes are transmitted by place value with a pause between the digits; for example, code 32 would be sent as 3 flashes, a pause and 2 flashes. A slightly longer pause divides codes from each other. Be ready to count and record codes; the only way to repeat a code is to recycle the system. This method may be used to read either 2 or 3-digit codes. The Continuous Memory codes are separated from the other codes by 6 seconds, a single flash and another 6-second delay.







4. This test may be performed as often as necessary, switching between ON and OFF by depressing the throttle.
5. Exit the test by turning the ignition switch OFF, detaching the jumper at the diagnostic connector or releasing the test button on the scan tool.

## Clearing Codes

### CONTINUOUS MEMORY CODES

These codes are retained in memory for 40 warm-up cycles. To clear the codes for purposes of testing or confirming repair, perform the code reading procedure. When the fault codes begin to be displayed, de-activate the test either by disconnecting the jumper wire (if using a meter, MIL or message center) or by releasing the test button on the hand scanner. Stopping the test during code transmission will erase the Continuous Memory. Do not disconnect the negative battery cable to clear these codes; the Keep Alive memory will be cleared and a new code, 19, will be stored for loss of PCM power.

### KEEP ALIVE MEMORY

The Keep Alive Memory (KAM) contains the adaptive factors used by the processor to compensate for component tolerances and wear. It should not be routinely cleared during diagnosis. If an emission related part is replaced during repair, the KAM must be cleared. Failure to clear the KAM may cause severe driveability problems since the correction factor for the old component will be applied to the new component.

To clear the Keep Alive Memory, disconnect the negative battery cable for at least 5 minutes. After the memory is cleared and the battery reconnected, the vehicle must be driven at least 10 miles (16 km) so that the processor may relearn the needed correction factors. The distance to be driven depends on the engine and vehicle, but all drives should include steady-throttle cruise on open roads. Certain driveability problems may be noted during the drive because the adaptive factors are not yet functioning.

### Other Test Modes

#### CONTINUOUS MONITOR OR WIGGLE TEST

Once entered, this mode allows the operator to attempt to recreate intermittent faults by wiggling or tapping components, wiring or connectors. The test may be performed during either KOEO or KOER procedures. The test requires the use of either an analog voltmeter or a hand-held scan tool.

To enter the continuous monitor mode during KOEO testing, turn the ignition switch ON. Activate the test, wait 10 seconds, then deactivate, and reactivate the test; the system will enter the continuous monitor mode. Tap, move, or wiggle the harness, component or connector suspected of causing the problem; if a fault is detected, the code will store in the memory. When the fault occurs, the dash-warning lamp will illuminate, the STAR tester will light a red indicator (and possibly beep) and the analog meter needle will sweep once.

To enter this mode in the KOER test:

1. Start the engine and run it at 2000 rpm for two minutes. This action warms up the oxygen sensor.
2. Turn the ignition switch OFF for 10 seconds.

3. Start the engine.
4. Activate the test, wait 10 seconds, then deactivate, and reactivate the test; the system will enter the continuous monitor mode.
5. Tap, move, or wiggle the harness, component or connector suspected of causing the problem; if a fault is detected, the code will store in the memory.
6. When the fault occurs, the dash-warning lamp will illuminate, the STAR tester will light a red indicator (and possibly beep) and the analog meter needle will sweep once.

#### OUTPUT STATE CHECK

This testing mode allows the operator to energize and de-energize most of the outputs controlled by the EEC-IV system. Many of the outputs may be checked at the component by listening for a click or feeling the item move or engage by a hand placed on the case. To enter this check:

1. Enter the KOEO test mode.
2. When all codes have been transmitted, depress the accelerator all the way to the floor and release it.
3. The output actuators are now all ON. Depressing the throttle pedal to the floor again switches the all the actuator outputs OFF.

## TROUBLE CODES —EEC-V SYSTEM (OBD-II)

### General Information

The Powertrain Control Module (PCM) is given responsibility for the operation of the emission control devices, cooling fans, ignition and advance and in some cases, automatic transmission functions. Because the EEC-V oversees both the ignition timing and the fuel injection operation, a precise air/fuel ratio will be maintained under all operating conditions. The PCM is a microprocessor or small computer that receives electrical inputs from several sensors, switches, and relays on and around the engine.

Based on combinations of these inputs, the PCM controls various output devices concerned with engine operation and emissions. The control module relies on the signals to form a correct picture of current vehicle operation. If any of the input signals is incorrect, the PCM reacts to whatever picture is painted for it. For example, if the coolant

temperature sensor is inaccurate and reads too low, the PCM may see a picture of the engine never warming up. Consequently, the engine settings will be maintained as if the engine were cold. Because so many inputs can affect one output, correct diagnostic procedures are essential on these systems.

One part of the PCM is devoted to monitoring both input and output functions within the system. This ability forms the core of the self-diagnostic system. If a problem is detected within a circuit, the control module will recognize the fault, assign it an Diagnostic Trouble Code (DTC), and store the code in memory. The stored code(s) may be retrieved during diagnosis.

While the EEC-V system is capable of recognizing many internal faults, certain faults will not be recognized. Because the control module sees only electrical signals, it cannot sense or react to mechanical or vacuum faults affecting engine oper-

ation. Some of these faults may affect another component which will set a code. For example, the PCM monitors the output signal to the fuel injectors, but cannot detect a partially clogged injector. As long as the output driver responds correctly, the computer will read the system as functioning correctly. However, the improper flow of fuel may result in a lean mixture. This would, in turn, be detected by the oxygen sensor and noticed as a constantly lean signal by the PCM. Once the signal falls outside the pre-programmed limits, the control module would notice the fault and set a trouble code.

Additionally, the EEC-V system employs adaptive fuel logic. This process is used to compensate for normal wear and variability within the fuel system. Once the engine enters steady-state operation, the control module watches the oxygen sensor signal for a bias or tendency to run slightly rich or lean. If such a bias is detected, the adaptive logic corrects

the fuel delivery to bring the air/fuel mixture towards a centered or 14.7:1 ratio. This compensating shift is stored in a non-volatile memory which is retained by battery power even with the ignition switched **OFF**. The correction factor is then available the next time the vehicle is operated.

## Malfunction Indicator Lamp

The Malfunction Indicator Lamp (MIL) is located on the instrument panel. The lamp is connected to the PCM and will alert the driver to certain malfunctions within the EEC-V system. When the lamp is illuminated, the PCM has detected a fault and stored a DTC in memory.

The light will stay illuminated as long as the fault is present. Should the fault self-correct, the MIL will extinguish but the stored code will remain in memory.

Under normal operating conditions, the MIL should illuminate briefly when the ignition key is turned **ON**. This is commonly known as a prove-out. As soon as the PCM receives a signal that the engine is cranking, the lamp should extinguish. The lamp should remain extinguished during the normal operating cycle.

## Data Link Connector

The Data Link Connector (DLC) may be found in the following location:

- Under the driver's side dashboard, near the steering column.

The DLC is rectangular in design and capable of allowing access to 16 terminals. The connector has keying features that allow easy connection. The test equipment and the DLC have a latching feature to ensure a good mated connection.

## ELECTRICAL TOOLS

The most commonly required electrical diagnostic tool is the Digital Multimeter, allowing voltage, resistance, and amperage to be read by one instrument.


The multimeter must be a high impedance unit, with 10 megohms of impedance in the voltmeter. This type of meter will not place an additional load on the circuit it is testing; this is extremely important in low voltage circuits. The multimeter must be of high quality in all respects. It should be handled carefully and protected from impact or damage. Replace the batteries frequently in the unit.

## Reading Codes

### ▶ See Figure 82

The EEC-V equipped engines utilize On Board Diagnostic II (OBD-II) DTC's, which are alphanumeric (they use letters and numbers). The letters in the OBD-II DTC's make it highly difficult to convey the codes through the use of anything but a scan tool. Therefore, to read the codes on these vehicles it is necessary to utilize an OBD-II compatible scan tool.

Since each manufacturer's scan tool is different, please follow the manufacturer's instructions for connecting the tool and obtaining code information.



**Fig. 82** When using a scan tool, make sure to follow all of the manufacturer's instructions carefully to ensure proper diagnosis

## Clearing Codes

### CONTINUOUS MEMORY CODES

These codes are retained in memory for 40 warm-up cycles. To clear the codes for the purposes of testing or confirming repair, perform the code reading procedure. When the fault codes begin to be displayed, de-activate the test by either disconnecting the jumper wire (meter, MIL or message center) or releasing the test button on the hand scanner. Stopping the test during code transmission will erase the Continuous Memory. Do not disconnect the negative battery cable to clear these codes; the Keep Alive memory will be cleared and a new code, 19, will be stored for loss of PCM power.

### KEEP ALIVE MEMORY

The Keep Alive Memory (KAM) contains the adaptive factors used by the processor to compensate for component tolerances and wear. It should not be routinely cleared during diagnosis. If an emissions related part is replaced during repair, the KAM must be cleared. Failure to clear the KAM may cause severe driveability problems since the correction factor for the old component will be applied to the new component.

To clear the Keep Alive Memory, disconnect the negative battery cable for at least 5 minutes. After the memory is cleared and the battery reconnected, the vehicle must be driven at least 10 miles so that the processor may relearn the needed correction factors. The distance to be driven depends on the engine and vehicle, but all drives should include steady-throttle cruise on open roads. Certain driveability problems may be noted during the drive because the adaptive factors are not yet functioning.

## EEC-V Diagnostic Trouble Codes (DTC's)

- P0000** No Failures
- P0100** Mass or Volume Air Flow Circuit Malfunction
- P0101** Mass or Volume Air Flow Circuit Range/Performance Problem
- P0102** Mass or Volume Air Flow Circuit Low Input
- P0103** Mass or Volume Air Flow Circuit High Input

- P0104** Mass or Volume Air Flow Circuit Intermittent
- P0105** Manifold Absolute Pressure/Barometric Pressure Circuit Malfunction
- P0106** Manifold Absolute Pressure/Barometric Pressure Circuit Range/Performance Problem
- P0107** Manifold Absolute Pressure/Barometric Pressure Circuit Low Input
- P0108** Manifold Absolute Pressure/Barometric Pressure Circuit High Input
- P0109** Manifold Absolute Pressure/Barometric Pressure Circuit Intermittent
- P0110** Intake Air Temperature Circuit Malfunction
- P0111** Intake Air Temperature Circuit Range/Performance Problem
- P0112** Intake Air Temperature Circuit Low Input
- P0113** Intake Air Temperature Circuit High Input
- P0114** Intake Air Temperature Circuit Intermittent
- P0115** Engine Coolant Temperature Circuit Malfunction
- P0116** Engine Coolant Temperature Circuit Range/Performance Problem
- P0117** Engine Coolant Temperature Circuit Low Input
- P0118** Engine Coolant Temperature Circuit High Input
- P0119** Engine Coolant Temperature Circuit Intermittent
- P0120** Throttle/Pedal Position Sensor/Switch "A" Circuit Malfunction
- P0121** Throttle/Pedal Position Sensor/Switch "A" Circuit Range/Performance Problem
- P0122** Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input
- P0123** Throttle/Pedal Position Sensor/Switch "A" Circuit High Input
- P0124** Throttle/Pedal Position Sensor/Switch "A" Circuit Intermittent
- P0125** Insufficient Coolant Temperature For Closed Loop Fuel Control
- P0126** Insufficient Coolant Temperature For Stable Operation
- P0130** O2 Circuit Malfunction (Bank 1 Sensor 1)
- P0131** O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)
- P0132** O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)
- P0133** O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)
- P0134** O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)
- P0135** O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)
- P0136** O2 Sensor Circuit Malfunction (Bank 1 Sensor 2)
- P0137** O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)
- P0138** O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)
- P0139** O2 Sensor Circuit Slow Response (Bank 1 Sensor 2)
- P0140** O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)
- P0141** O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)
- P0142** O2 Sensor Circuit Malfunction (Bank 1 Sensor 3)
- P0143** O2 Sensor Circuit Low Voltage (Bank 1 Sensor 3)

- P0144** O2 Sensor Circuit High Voltage (Bank 1 Sensor 3)
- P0145** O2 Sensor Circuit Slow Response (Bank 1 Sensor 3)
- P0146** O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 3)
- P0147** O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 3)
- P0150** O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)
- P0151** O2 Sensor Circuit Low Voltage (Bank 2 Sensor 1)
- P0152** O2 Sensor Circuit High Voltage (Bank 2 Sensor 1)
- P0153** O2 Sensor Circuit Slow Response (Bank 2 Sensor 1)
- P0154** O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)
- P0155** O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)
- P0156** O2 Sensor Circuit Malfunction (Bank 2 Sensor 2)
- P0157** O2 Sensor Circuit Low Voltage (Bank 2 Sensor 2)
- P0158** O2 Sensor Circuit High Voltage (Bank 2 Sensor 2)
- P0159** O2 Sensor Circuit Slow Response (Bank 2 Sensor 2)
- P0160** O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 2)
- P0161** O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)
- P0162** O2 Sensor Circuit Malfunction (Bank 2 Sensor 3)
- P0163** O2 Sensor Circuit Low Voltage (Bank 2 Sensor 3)
- P0164** O2 Sensor Circuit High Voltage (Bank 2 Sensor 3)
- P0165** O2 Sensor Circuit Slow Response (Bank 2 Sensor 3)
- P0166** O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 3)
- P0167** O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 3)
- P0170** Fuel Trim Malfunction (Bank 1)
- P0171** System Too Lean (Bank 1)
- P0172** System Too Rich (Bank 1)
- P0173** Fuel Trim Malfunction (Bank 2)
- P0174** System Too Lean (Bank 2)
- P0175** System Too Rich (Bank 2)
- P0180** Fuel Temperature Sensor "A" Circuit Malfunction
- P0181** Fuel Temperature Sensor "A" Circuit Range/Performance
- P0182** Fuel Temperature Sensor "A" Circuit Low Input
- P0183** Fuel Temperature Sensor "A" Circuit High Input
- P0184** Fuel Temperature Sensor "A" Circuit Intermittent
- P0185** Fuel Temperature Sensor "B" Circuit Malfunction
- P0186** Fuel Temperature Sensor "B" Circuit Range/Performance
- P0187** Fuel Temperature Sensor "B" Circuit Low Input
- P0188** Fuel Temperature Sensor "B" Circuit High Input
- P0189** Fuel Temperature Sensor "B" Circuit Intermittent
- P0190** Fuel Rail Pressure Sensor Circuit Malfunction
- P0191** Fuel Rail Pressure Sensor Circuit Range/Performance
- P0192** Fuel Rail Pressure Sensor Circuit Low Input
- P0193** Fuel Rail Pressure Sensor Circuit High Input
- P0194** Fuel Rail Pressure Sensor Circuit Intermittent
- P0200** Injector Circuit Malfunction
- P0201** Injector Circuit Malfunction —Cylinder 1
- P0202** Injector Circuit Malfunction —Cylinder 2
- P0203** Injector Circuit Malfunction —Cylinder 3
- P0204** Injector Circuit Malfunction —Cylinder 4
- P0205** Injector Circuit Malfunction —Cylinder 5
- P0206** Injector Circuit Malfunction —Cylinder 6
- P0207** Injector Circuit Malfunction —Cylinder 7
- P0208** Injector Circuit Malfunction —Cylinder 8
- P0215** Engine Shutoff Solenoid Malfunction
- P0217** Engine Over Temperature Condition
- P0218** Transmission Over Temperature Condition
- P0219** Engine Over Speed Condition
- P0220** Throttle/Pedal Position Sensor/Switch "B" Circuit Malfunction
- P0221** Throttle/Pedal Position Sensor/Switch "B" Circuit Range/Performance Problem
- P0222** Throttle/Pedal Position Sensor/Switch "B" Circuit Low Input
- P0223** Throttle/Pedal Position Sensor/Switch "B" Circuit High Input
- P0224** Throttle/Pedal Position Sensor/Switch "B" Circuit Intermittent
- P0225** Throttle/Pedal Position Sensor/Switch "C" Circuit Malfunction
- P0226** Throttle/Pedal Position Sensor/Switch "C" Circuit Range/Performance Problem
- P0227** Throttle/Pedal Position Sensor/Switch "C" Circuit Low Input
- P0228** Throttle/Pedal Position Sensor/Switch "C" Circuit High Input
- P0229** Throttle/Pedal Position Sensor/Switch "C" Circuit Intermittent
- P0230** Fuel Pump Primary Circuit Malfunction
- P0231** Fuel Pump Secondary Circuit Low
- P0232** Fuel Pump Secondary Circuit High
- P0233** Fuel Pump Secondary Circuit Intermittent
- P0261** Cylinder 1 Injector Circuit Low
- P0262** Cylinder 1 Injector Circuit High
- P0263** Cylinder 1 Contribution/Balance Fault
- P0264** Cylinder 2 Injector Circuit Low
- P0265** Cylinder 2 Injector Circuit High
- P0266** Cylinder 2 Contribution/Balance Fault
- P0267** Cylinder 3 Injector Circuit Low
- P0268** Cylinder 3 Injector Circuit High
- P0269** Cylinder 3 Contribution/Balance Fault
- P0270** Cylinder 4 Injector Circuit Low
- P0271** Cylinder 4 Injector Circuit High
- P0272** Cylinder 4 Contribution/Balance Fault
- P0273** Cylinder 5 Injector Circuit Low
- P0274** Cylinder 5 Injector Circuit High
- P0275** Cylinder 5 Contribution/Balance Fault
- P0276** Cylinder 6 Injector Circuit Low
- P0277** Cylinder 6 Injector Circuit High
- P0278** Cylinder 6 Contribution/Balance Fault
- P0279** Cylinder 7 Injector Circuit Low
- P0280** Cylinder 7 Injector Circuit High
- P0281** Cylinder 7 Contribution/Balance Fault
- P0282** Cylinder 8 Injector Circuit Low
- P0283** Cylinder 8 Injector Circuit High
- P0284** Cylinder 8 Contribution/Balance Fault
- P0300** Random/Multiple Cylinder Misfire Detected
- P0301** Cylinder 1 —Misfire Detected
- P0302** Cylinder 2 —Misfire Detected
- P0303** Cylinder 3 —Misfire Detected
- P0304** Cylinder 4 —Misfire Detected
- P0305** Cylinder 5 —Misfire Detected
- P0306** Cylinder 6 —Misfire Detected
- P0307** Cylinder 7 —Misfire Detected
- P0308** Cylinder 8 —Misfire Detected
- P0320** Ignition/Distributor Engine Speed Input Circuit Malfunction
- P0321** Ignition/Distributor Engine Speed Input Circuit Range/Performance
- P0322** Ignition/Distributor Engine Speed Input Circuit No Signal
- P0323** Ignition/Distributor Engine Speed Input Circuit Intermittent
- P0325** Knock Sensor 1 —Circuit Malfunction (Bank 1 or Single Sensor)
- P0326** Knock Sensor 1 —Circuit Range/Performance (Bank 1 or Single Sensor)
- P0327** Knock Sensor 1 —Circuit Low Input (Bank 1 or Single Sensor)
- P0328** Knock Sensor 1 —Circuit High Input (Bank 1 or Single Sensor)
- P0329** Knock Sensor 1 —Circuit Input Intermittent (Bank 1 or Single Sensor)
- P0330** Knock Sensor 2 —Circuit Malfunction (Bank 2)
- P0331** Knock Sensor 2 —Circuit Range/Performance (Bank 2)
- P0332** Knock Sensor 2 —Circuit Low Input (Bank 2)
- P0333** Knock Sensor 2 —Circuit High Input (Bank 2)
- P0334** Knock Sensor 2 —Circuit Input Intermittent (Bank 2)
- P0335** Crankshaft Position Sensor "A" Circuit Malfunction
- P0336** Crankshaft Position Sensor "A" Circuit Range/Performance
- P0337** Crankshaft Position Sensor "A" Circuit Low Input
- P0338** Crankshaft Position Sensor "A" Circuit High Input
- P0339** Crankshaft Position Sensor "A" Circuit Intermittent
- P0340** Camshaft Position Sensor Circuit Malfunction
- P0341** Camshaft Position Sensor Circuit Range/Performance
- P0342** Camshaft Position Sensor Circuit Low Input
- P0343** Camshaft Position Sensor Circuit High Input
- P0344** Camshaft Position Sensor Circuit Intermittent
- P0350** Ignition Coil Primary/Secondary Circuit Malfunction
- P0351** Ignition Coil "A" Primary/Secondary Circuit Malfunction
- P0352** Ignition Coil "B" Primary/Secondary Circuit Malfunction
- P0353** Ignition Coil "C" Primary/Secondary Circuit Malfunction
- P0354** Ignition Coil "D" Primary/Secondary Circuit Malfunction



# 4-24 DRIVEABILITY AND EMISSIONS CONTROLS

- P0355** Ignition Coil "E" Primary/Secondary Circuit Malfunction
- P0356** Ignition Coil "F" Primary/Secondary Circuit Malfunction
- P0357** Ignition Coil "G" Primary/Secondary Circuit Malfunction
- P0358** Ignition Coil "H" Primary/Secondary Circuit Malfunction
- P0359** Ignition Coil "I" Primary/Secondary Circuit Malfunction
- P0360** Ignition Coil "J" Primary/Secondary Circuit Malfunction
- P0361** Ignition Coil "K" Primary/Secondary Circuit Malfunction
- P0362** Ignition Coil "L" Primary/Secondary Circuit Malfunction
- P0370** Timing Reference High Resolution Signal "A" Malfunction
- P0371** Timing Reference High Resolution Signal "A" Too Many Pulses
- P0372** Timing Reference High Resolution Signal "A" Too Few Pulses
- P0373** Timing Reference High Resolution Signal "A" Intermittent/Erratic Pulses
- P0374** Timing Reference High Resolution Signal "A" No Pulses
- P0375** Timing Reference High Resolution Signal "B" Malfunction
- P0376** Timing Reference High Resolution Signal "B" Too Many Pulses
- P0377** Timing Reference High Resolution Signal "B" Too Few Pulses
- P0378** Timing Reference High Resolution Signal "B" Intermittent/Erratic Pulses
- P0379** Timing Reference High Resolution Signal "B" No Pulses
- P0385** Crankshaft Position Sensor "B" Circuit Malfunction
- P0386** Crankshaft Position Sensor "B" Circuit Range/Performance
- P0387** Crankshaft Position Sensor "B" Circuit Low Input
- P0388** Crankshaft Position Sensor "B" Circuit High Input
- P0389** Crankshaft Position Sensor "B" Circuit Intermittent
- P0400** Exhaust Gas Recirculation Flow Malfunction
- P0401** Exhaust Gas Recirculation Flow Insufficient Detected
- P0402** Exhaust Gas Recirculation Flow Excessive Detected
- P0403** Exhaust Gas Recirculation Circuit Malfunction
- P0404** Exhaust Gas Recirculation Circuit Range/Performance
- P0405** Exhaust Gas Recirculation Sensor "A" Circuit Low
- P0406** Exhaust Gas Recirculation Sensor "A" Circuit High
- P0407** Exhaust Gas Recirculation Sensor "B" Circuit Low
- P0408** Exhaust Gas Recirculation Sensor "B" Circuit High
- P0410** Secondary Air Injection System Malfunction
- P0411** Secondary Air Injection System Incorrect Flow Detected
- P0412** Secondary Air Injection System Switching Valve "A" Circuit Malfunction
- P0413** Secondary Air Injection System Switching Valve "A" Circuit Open
- P0414** Secondary Air Injection System Switching Valve "A" Circuit Shorted
- P0415** Secondary Air Injection System Switching Valve "B" Circuit Malfunction
- P0416** Secondary Air Injection System Switching Valve "B" Circuit Open
- P0417** Secondary Air Injection System Switching Valve "B" Circuit Shorted
- P0418** Secondary Air Injection System Relay "A" Circuit Malfunction
- P0419** Secondary Air Injection System Relay "B" Circuit Malfunction
- P0420** Catalyst System Efficiency Below Threshold (Bank 1)
- P0421** Warm Up Catalyst Efficiency Below Threshold (Bank 1)
- P0422** Main Catalyst Efficiency Below Threshold (Bank 1)
- P0423** Heated Catalyst Efficiency Below Threshold (Bank 1)
- P0424** Heated Catalyst Temperature Below Threshold (Bank 1)
- P0430** Catalyst System Efficiency Below Threshold (Bank 2)
- P0431** Warm Up Catalyst Efficiency Below Threshold (Bank 2)
- P0432** Main Catalyst Efficiency Below Threshold (Bank 2)
- P0433** Heated Catalyst Efficiency Below Threshold (Bank 2)
- P0434** Heated Catalyst Temperature Below Threshold (Bank 2)
- P0440** Evaporative Emission Control System Malfunction
- P0441** Evaporative Emission Control System Incorrect Purge Flow
- P0442** Evaporative Emission Control System Leak Detected (Small Leak)
- P0443** Evaporative Emission Control System Purge Control Valve Circuit Malfunction
- P0444** Evaporative Emission Control System Purge Control Valve Circuit Open
- P0445** Evaporative Emission Control System Purge Control Valve Circuit Shorted
- P0446** Evaporative Emission Control System Vent Control Circuit Malfunction
- P0447** Evaporative Emission Control System Vent Control Circuit Open
- P0448** Evaporative Emission Control System Vent Control Circuit Shorted
- P0449** Evaporative Emission Control System Vent Valve/Solenoid Circuit Malfunction
- P0450** Evaporative Emission Control System Pressure Sensor Malfunction
- P0451** Evaporative Emission Control System Pressure Sensor Range/Performance
- P0452** Evaporative Emission Control System Pressure Sensor Low Input
- P0453** Evaporative Emission Control System Pressure Sensor High Input
- P0454** Evaporative Emission Control System Pressure Sensor Intermittent
- P0455** Evaporative Emission Control System Leak Detected (Gross Leak)
- P0460** Fuel Level Sensor Circuit Malfunction
- P0461** Fuel Level Sensor Circuit Range/Performance
- P0462** Fuel Level Sensor Circuit Low Input
- P0463** Fuel Level Sensor Circuit High Input
- P0464** Fuel Level Sensor Circuit Intermittent
- P0465** Purge Flow Sensor Circuit Malfunction
- P0466** Purge Flow Sensor Circuit Range/Performance
- P0467** Purge Flow Sensor Circuit Low Input
- P0468** Purge Flow Sensor Circuit High Input
- P0469** Purge Flow Sensor Circuit Intermittent
- P0480** Cooling Fan 1 Control Circuit Malfunction
- P0481** Cooling Fan 2 Control Circuit Malfunction
- P0482** Cooling Fan 3 Control Circuit Malfunction
- P0483** Cooling Fan Rationality Check Malfunction
- P0484** Cooling Fan Circuit Over Current
- P0485** Cooling Fan Power/Ground Circuit Malfunction
- P0500** Vehicle Speed Sensor Malfunction
- P0501** Vehicle Speed Sensor Range/Performance
- P0502** Vehicle Speed Sensor Circuit Low Input
- P0503** Vehicle Speed Sensor Intermittent/Erratic/High
- P0505** Idle Control System Malfunction
- P0506** Idle Control System RPM Lower Than Expected
- P0507** Idle Control System RPM Higher Than Expected
- P0510** Closed Throttle Position Switch Malfunction
- P0530** A/C Refrigerant Pressure Sensor Circuit Malfunction
- P0531** A/C Refrigerant Pressure Sensor Circuit Range/Performance
- P0532** A/C Refrigerant Pressure Sensor Circuit Low Input
- P0533** A/C Refrigerant Pressure Sensor Circuit High Input
- P0534** A/C Refrigerant Charge Loss
- P0550** Power Steering Pressure Sensor Circuit Malfunction
- P0551** Power Steering Pressure Sensor Circuit Range/Performance
- P0552** Power Steering Pressure Sensor Circuit Low Input
- P0553** Power Steering Pressure Sensor Circuit High Input
- P0554** Power Steering Pressure Sensor Circuit Intermittent
- P0560** System Voltage Malfunction
- P0561** System Voltage Unstable
- P0562** System Voltage Low
- P0563** System Voltage High
- P0565** Cruise Control On Signal Malfunction
- P0566** Cruise Control Off Signal Malfunction
- P0567** Cruise Control Resume Signal Malfunction
- P0568** Cruise Control Set Signal Malfunction
- P0569** Cruise Control Coast Signal Malfunction
- P0570** Cruise Control Accel Signal Malfunction
- P0571** Cruise Control/Brake Switch "A" Circuit Malfunction
- P0572** Cruise Control/Brake Switch "A" Circuit Low
- P0573** Cruise Control/Brake Switch "A" Circuit High
- P0574 Through P0580** Reserved for Cruise Codes

- P0600** Serial Communication Link Malfunction
- P0601** Internal Control Module Memory Check Sum Error
- P0602** Control Module Programming Error
- P0603** Internal Control Module Keep Alive Memory (KAM) Error
- P0604** Internal Control Module Random Access Memory (RAM) Error
- P0605** Internal Control Module Read Only Memory (ROM) Error
- P0606** PCM Processor Fault
- P0608** Control Module VSS Output "A" Malfunction
- P0609** Control Module VSS Output "B" Malfunction
- P0620** Generator Control Circuit Malfunction
- P0621** Generator Lamp "L" Control Circuit Malfunction
- P0622** Generator Field "F" Control Circuit Malfunction
- P0650** Malfunction Indicator Lamp (MIL) Control Circuit Malfunction
- P0654** Engine RPM Output Circuit Malfunction
- P0655** Engine Hot Lamp Output Control Circuit Malfunction
- P0656** Fuel Level Output Circuit Malfunction
- P0700** Transmission Control System Malfunction
- P0701** Transmission Control System Range/Performance
- P0702** Transmission Control System Electrical Malfunction
- P0703** Torque Converter/Brake Switch "B" Circuit Malfunction
- P0704** Clutch Switch Input Circuit Malfunction
- P0705** Transmission Range Sensor Circuit Malfunction (PRNDL Input)
- P0706** Transmission Range Sensor Circuit Range/Performance
- P0707** Transmission Range Sensor Circuit Low Input
- P0708** Transmission Range Sensor Circuit High Input
- P0709** Transmission Range Sensor Circuit Intermittent
- P0710** Transmission Fluid Temperature Sensor Circuit Malfunction
- P0711** Transmission Fluid Temperature Sensor Circuit Range/Performance
- P0712** Transmission Fluid Temperature Sensor Circuit Low Input
- P0713** Transmission Fluid Temperature Sensor Circuit High Input
- P0714** Transmission Fluid Temperature Sensor Circuit Intermittent
- P0715** Input/Turbine Speed Sensor Circuit Malfunction
- P0716** Input/Turbine Speed Sensor Circuit Range/Performance
- P0717** Input/Turbine Speed Sensor Circuit No Signal
- P0718** Input/Turbine Speed Sensor Circuit Intermittent
- P0719** Torque Converter/Brake Switch "B" Circuit Low
- P0720** Output Speed Sensor Circuit Malfunction
- P0721** Output Speed Sensor Circuit Range/Performance
- P0722** Output Speed Sensor Circuit No Signal
- P0723** Output Speed Sensor Circuit Intermittent
- P0724** Torque Converter/Brake Switch "B" Circuit High
- P0725** Engine Speed Input Circuit Malfunction
- P0726** Engine Speed Input Circuit Range/Performance
- P0727** Engine Speed Input Circuit No Signal
- P0728** Engine Speed Input Circuit Intermittent
- P0730** Incorrect Gear Ratio
- P0731** Gear 1 Incorrect Ratio
- P0732** Gear 2 Incorrect Ratio
- P0733** Gear 3 Incorrect Ratio
- P0734** Gear 4 Incorrect Ratio
- P0735** Gear 5 Incorrect Ratio
- P0736** Reverse Incorrect Ratio
- P0740** Torque Converter Clutch Circuit Malfunction
- P0741** Torque Converter Clutch Circuit Performance or Stuck Off
- P0742** Torque Converter Clutch Circuit Stuck On
- P0743** Torque Converter Clutch Circuit Electrical
- P0744** Torque Converter Clutch Circuit Intermittent
- P0745** Pressure Control Solenoid Malfunction
- P0746** Pressure Control Solenoid Performance or Stuck Off
- P0747** Pressure Control Solenoid Stuck On
- P0748** Pressure Control Solenoid Electrical
- P0749** Pressure Control Solenoid Intermittent
- P0750** Shift Solenoid "A" Malfunction
- P0751** Shift Solenoid "A" Performance or Stuck Off
- P0752** Shift Solenoid "A" Stuck On
- P0753** Shift Solenoid "A" Electrical
- P0754** Shift Solenoid "A" Intermittent
- P0755** Shift Solenoid "B" Malfunction
- P0756** Shift Solenoid "B" Performance or Stuck Off
- P0757** Shift Solenoid "B" Stuck On
- P0758** Shift Solenoid "B" Electrical
- P0759** Shift Solenoid "B" Intermittent
- P0760** Shift Solenoid "C" Malfunction
- P0761** Shift Solenoid "C" Performance Or Stuck Off
- P0762** Shift Solenoid "C" Stuck On
- P0763** Shift Solenoid "C" Electrical
- P0764** Shift Solenoid "C" Intermittent
- P0765** Shift Solenoid "D" Malfunction
- P0766** Shift Solenoid "D" Performance Or Stuck Off
- P0767** Shift Solenoid "D" Stuck On
- P0768** Shift Solenoid "D" Electrical
- P0769** Shift Solenoid "D" Intermittent
- P0770** Shift Solenoid "E" Malfunction
- P0771** Shift Solenoid "E" Performance Or Stuck Off
- P0772** Shift Solenoid "E" Stuck On
- P0773** Shift Solenoid "E" Electrical
- P0774** Shift Solenoid "E" Intermittent
- P0780** Shift Malfunction
- P0781** 1-2 Shift Malfunction
- P0782** 2-3 Shift Malfunction
- P0783** 3-4 Shift Malfunction
- P0784** 4-5 Shift Malfunction
- P0785** Shift/Timing Solenoid Malfunction
- P0786** Shift/Timing Solenoid Range/Performance
- P0787** Shift/Timing Solenoid Low
- P0788** Shift/Timing Solenoid High
- P0789** Shift/Timing Solenoid Intermittent
- P0790** Normal/Performance Switch Circuit Malfunction
- P0801** Reverse Inhibit Control Circuit Malfunction
- P0803** 1-4 Upshift (Skip Shift) Solenoid Control Circuit Malfunction
- P0804** 1-4 Upshift (Skip Shift) Lamp Control Circuit Malfunction
- P1000** OBD II Monitor Testing Not Complete More Driving Required
- P1001** Key On Engine Running (KOER) Self-Test Not Able To Complete, KOER Aborted
- P1100** Mass Air Flow (MAF) Sensor Intermittent
- P1101** Mass Air Flow (MAF) Sensor Out Of Self-Test Range
- P1111** System Pass 49 State
- P1112** Intake Air Temperature (IAT) Sensor Intermittent
- P1116** Engine Coolant Temperature (ECT) Sensor Out Of Self-Test Range
- P1117** Engine Coolant Temperature (ECT) Sensor Intermittent
- P1120** Throttle Position (TP) Sensor Out Of Range (Low)
- P1121** Throttle Position (TP) Sensor Inconsistent With MAF Sensor
- P1124** Throttle Position (TP) Sensor Out Of Self-Test Range
- P1125** Throttle Position (TP) Sensor Circuit Intermittent
- P1127** Exhaust Not Warm Enough, Downstream Heated Oxygen Sensors (HO<sub>2</sub>S) Not Tested
- P1128** Upstream Heated Oxygen Sensors (HO<sub>2</sub>S) Swapped From Bank To Bank
- P1129** Downstream Heated Oxygen Sensors (HO<sub>2</sub>S) Swapped From Bank To Bank
- P1130** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 11) Switch, Adaptive Fuel At Limit (Bank #1)
- P1131** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 11) Switch, Sensor Indicates Lean (Bank #1)
- P1132** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 11) Switch, Sensor Indicates Rich (Bank#1)
- P1137** Lack Of Downstream Heated Oxygen Sensor (HO<sub>2</sub>S 12) Switch, Sensor Indicates Lean (Bank#1)
- P1138** Lack Of Downstream Heated Oxygen Sensor (HO<sub>2</sub>S 12) Switch, Sensor Indicates Rich (Bank#1)
- P1150** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 21) Switch, Adaptive Fuel At Limit (Bank #2)
- P1151** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 21) Switch, Sensor Indicates Lean (Bank#2)
- P1152** Lack Of Upstream Heated Oxygen Sensor (HO<sub>2</sub>S 21) Switch, Sensor Indicates Rich (Bank #2)
- P1157** Lack Of Downstream Heated Oxygen Sensor (HO<sub>2</sub>S 22) Switch, Sensor Indicates Lean (Bank #2)
- P1158** Lack Of Downstream Heated Oxygen Sensor (HO<sub>2</sub>S 22) Switch, Sensor Indicates Rich (Bank#2)
- P1169** (HO<sub>2</sub>S 12) Signal Remained Unchanged For More Than 20 Seconds After Closed Loop
- P1170** (HO<sub>2</sub>S 11) Signal Remained Unchanged For More Than 20 Seconds After Closed Loop

# 4-26 DRIVEABILITY AND EMISSIONS CONTROLS

- P1173** Feedback A/F Mixture Control (HO<sub>2</sub>S 21) Signal Remained Unchanged For More Than 20 Seconds After Closed Loop
- P1195** Barometric (BARO) Pressure Sensor Circuit Malfunction (Signal Is From EGR Boost Sensor)
- P1196** Starter Switch Circuit Malfunction
- P1218** Cylinder Identification (CID) Stuck High
- P1219** Cylinder Identification (CID) Stuck Low
- P1220** Series Throttle Control Malfunction (Traction Control System)
- P1224** Throttle Position Sensor "B" (TP-B) Out Of Self-Test Range (Traction Control System)
- P1230** Fuel Pump Low Speed Malfunction
- P1231** Fuel Pump Secondary Circuit Low With High Speed Pump On
- P1232** Low Speed Fuel Pump Primary Circuit Malfunction
- P1233** Fuel Pump Driver Module Off-line (MIL DTC)
- P1234** Fuel Pump Driver Module Disabled Or Off-line (No MIL)
- P1235** Fuel Pump Control Out Of Range (MIL DTC)
- P1236** Fuel Pump Control Out Of Range (No MIL)
- P1237** Fuel Pump Secondary Circuit Malfunction (MIL DTC)
- P1238** Fuel Pump Secondary Circuit Malfunction (No DMIL)
- P1260** THEFT Detected —Engine Disabled
- P1261** High To Low Side Short —Cylinder #1 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1262** High To Low Side Short —Cylinder #2 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1263** High To Low Side Short —Cylinder #3 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1264** High To Low Side Short —Cylinder #4 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1265** High To Low Side Short —Cylinder #5 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1266** High To Low Side Short —Cylinder #6 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1267** High To Low Side Short —Cylinder #7 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1268** High To Low Side Short —Cylinder #8 (Indicates Low side Circuit Is Shorted To B+ Or To The High Side Between The IDM And The Injector)
- P1270** Engine RPM Or Vehicle Speed Limiter Reached
- P1271** High To Low Side Open —Cylinder #1 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1272** High To Low Side Open —Cylinder #2 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1273** High To Low Side Open —Cylinder #3 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1274** High To Low Side Open —Cylinder #4 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1275** High To Low Side Open —Cylinder #5 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1276** High To Low Side Open —Cylinder #6 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1277** High To Low Side Open —Cylinder #7 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1278** High To Low Side Open —Cylinder #8 (Indicates A High To Low Side Open Between The Injector And The IDM)
- P1285** Cylinder Head Temperature (CHT) Over Temperature Sensed
- P1288** Cylinder Head Temperature (CHT) Sensor Out Of Self-Test Range
- P1289** Cylinder Head Temperature (CHT) Sensor Circuit Low Input
- P1290** Cylinder Head Temperature (CHT) Sensor Circuit High Input
- P1299** Engine Over Temperature Condition Enabled
- P1309** Misfire Detection Monitor Is Not Enabled
- P1320** Distributor Signal Interrupt
- P1336** Crankshaft Position Sensor (Gear)
- P1345** No Camshaft Position Sensor Signal
- P1351** Ignition Diagnostic Monitor (IDM) Circuit Input Malfunction
- P1351** Indicates Ignition System Malfunction
- P1352** Indicates Ignition System Malfunction
- P1353** Indicates Ignition System Malfunction
- P1354** Indicates Ignition System Malfunction
- P1355** Indicates Ignition System Malfunction
- P1356** PIPs Occurred While IDM Pulse width Indicates Engine Not Turning
- P1357** Ignition Diagnostic Monitor (IDM) Pulse width Not Defined
- P1358** Ignition Diagnostic Monitor (IDM) Signal Out Of Self-Test Range
- P1359** Spark Output Circuit Malfunction
- P1364** Spark Output Circuit Malfunction
- P1390** Octane Adjust (OCT ADJ) Out Of Self-Test Range
- P1397** System Voltage Out Of Self Test Range
- P1400** Differential Pressure Feedback EGR (DPFE) Sensor Circuit Low Voltage Detected
- P1401** Differential Pressure Feedback EGR (DPFE) Sensor Circuit High Voltage Detected/EGR Temperature Sensor
- P1402** EGR Valve Position Sensor Open Or Short
- P1403** Differential Pressure Feedback EGR (DPFE) Sensor Hoses Reversed
- P1405** Differential Pressure Feedback EGR (DPFE) Sensor Upstream Hose Off Or Plugged
- P1406** Differential Pressure Feedback EGR (DPFE) Sensor Downstream Hose Off Or Plugged
- P1407** Exhaust Gas Recirculation (EGR) No Flow Detected (Valve Stuck Closed Or Inoperative)
- P1408** Exhaust Gas Recirculation (EGR) Flow Out Of Self-Test Range
- P1409** Electronic Vacuum Regulator (EVR) Control Circuit Malfunction
- P1410** Check That Fuel Pressure Regulator Control Solenoid And The EGR Check Solenoid Connectors Are Not Swapped
- P1411** Secondary Air Injection System Incorrect Downstream Flow Detected
- P1413** Secondary Air Injection System Monitor Circuit Low Voltage
- P1414** Secondary Air Injection System Monitor Circuit High Voltage
- P1442** Evaporative Emission Control System Small Leak Detected
- P1443** Evaporative Emission Control System —Vacuum System, Purge Control Solenoid Or Purge Control Valve Malfunction
- P1444** Purge Flow Sensor (PFS) Circuit Low Input
- P1445** Purge Flow Sensor (PFS) Circuit High Input
- P1449** Evaporative Emission Control System Unable To Hold Vacuum
- P1450** Unable To Bleed Up Fuel Tank Vacuum
- P1455** Evaporative Emission Control System Control Leak Detected (Gross Leak)
- P1460** Wide Open Throttle Air Conditioning Cut-Off Circuit Malfunction
- P1461** Air Conditioning Pressure (ACP) Sensor Circuit Low Input
- P1462** Air Conditioning Pressure (ACP) Sensor Circuit High Input
- P1463** Air Conditioning Pressure (ACP) Sensor Insufficient Pressure Change
- P1464** Air Conditioning (A/C) Demand Out Of Self-Test Range/A/C On During KOER Or CCT Test
- P1469** Low Air Conditioning Cycling Period
- P1473** Fan Secondary High, With Fan(s) Off
- P1474** Low Fan Control Primary Circuit Malfunction
- P1479** High Fan Control Primary Circuit Malfunction
- P1480** Fan Secondary Low, With Low Fan On
- P1481** Fan Secondary Low, With High Fan On
- P1483** Power To Fan Circuit Over current
- P1484** Open Power/Ground To Variable Load Control Module (VLCM)
- P1485** EGR Control Solenoid Open Or Short
- P1486** EGR Vent Solenoid Open Or Short
- P1487** EGR Boost Check Solenoid Open Or Short
- P1500** Vehicle Speed Sensor (VSS) Circuit Intermittent
- P1501** Vehicle Speed Sensor (VSS) Out Of Self-Test Range/Vehicle Moved During Test
- P1502** Invalid Self Test —Auxiliary Powertrain Control Module (APCM) Functioning
- P1504** Idle Air Control (IAC) Circuit Malfunction
- P1505** Idle Air Control (IAC) System At Adaptive Clip
- P1506** Idle Air Control (IAC) Overspeed Error
- P1507** Idle Air Control (IAC) Underspeed Error
- P1512** Intake Manifold Runner Control (IMRC) Malfunction (Bank#1 Stuck Closed)
- P1513** Intake Manifold Runner Control (IMRC) Malfunction (Bank#2 Stuck Closed)
- P1516** Intake Manifold Runner Control (IMRC) Input Error (Bank #1)
- P1517** Intake Manifold Runner Control (IMRC) Input Error (Bank #2)
- P1518** Intake Manifold Runner Control (IMRC) Malfunction (Stuck Open)
- P1519** Intake Manifold Runner Control (IMRC) Malfunction (Stuck Closed)
- P1520** Intake Manifold Runner Control (IMRC) Circuit Malfunction
- P1521** Variable Resonance Induction System (VRIS) Solenoid #1 Open Or Short
- P1522** Variable Resonance Induction System (VRIS) Solenoid #2 Open Or Short
- P1523** High Speed Inlet Air (HSIA) Solenoid Open Or Short



**P1530** Air Condition (A/C) Clutch Circuit Malfunction  
**P1531** Invalid Test —Accelerator Pedal Movement  
**P1536** Parking Brake Applied Failure  
**P1537** Intake Manifold Runner Control (IMRC) Malfunction (Bank#1 Stuck Open)  
**P1538** Intake Manifold Runner Control (IMRC) Malfunction (Bank#2 Stuck Open)  
**P1539** Power To Air Condition (A/C) Clutch Circuit Overcurrent  
**P1549** Problem In Intake Manifold Tuning (IMT) Valve System  
**P1550** Power Steering Pressure (PSP) Sensor Out Of Self-Test Range  
**P1601** Serial Communication Error  
**P1605** Powertrain Control Module (PCM) —Keep Alive Memory (KAM) Test Error  
**P1608** PCM Internal Circuit Malfunction  
**P1609** PCM Internal Circuit Malfunction (2.5L Only)  
**P1625** B+ Supply To Variable Load Control Module (VLCM) Fan Circuit Malfunction  
**P1626** B+ Supply To Variable Load Control Module (VLCM) Air Conditioning (A/C) Circuit  
**P1650** Power Steering Pressure (PSP) Switch Out Of Self-Test Range  
**P1651** Power Steering Pressure (PSP) Switch Input Malfunction  
**P1660** Output Circuit Check Signal High  
**P1661** Output Circuit Check Signal Low  
**P1663** Fuel Delivery Command Signal (FDCS) Circuit Failure  
**P1667** Cylinder Identification (CID) Circuit Failure  
**P1668** PCM —IDM Diagnostic Communication Error  
**P1670** EF Feedback Signal Not Detected  
**P1701** Reverse Engagement Error  
**P1703** Brake On/Off (BOO) Switch Out Of Self-Test Range  
**P1704** Digital Transmission Range (TR) Sensor Failed To Transition State

**P1705** Transmission Range (TR) Sensor Out Of Self-Test Range  
**P1705** Park Neutral Position (PNP) Problem  
**P1706** High Vehicle Speed In Park  
**P1709** Park Or Neutral Position (PNP) Switch Out Of Self-Test Range  
**P1711** Transmission Fluid Temperature (TFT) Sensor Out Of Self-Test Range  
**P1714** Shift Solenoid "A" Inductive Signature Malfunction  
**P1715** Shift Solenoid "B" Inductive Signature Malfunction  
**P1716** Transmission Malfunction  
**P1717** Transmission Malfunction  
**P1719** Transmission Malfunction  
**P1720** Vehicle Speed Sensor (VSS) Circuit Malfunction  
**P1727** Coast Clutch Solenoid Inductive Signature Malfunction  
**P1728** Transmission Slip Error —Converter Clutch Failed  
**P1731** Improper 1 —2 Shift  
**P1732** Improper 2 —3 Shift  
**P1733** Improper 3 —4 Shift  
**P1734** Improper 4 —5 Shift  
**P1740** Torque Converter Clutch (TCC) Inductive Signature Malfunction  
**P1741** Torque Converter Clutch (TCC) Control Error  
**P1742** Torque Converter Clutch (TCC) Solenoid Failed On (Turns On MIL)  
**P1743** Torque Converter Clutch (TCC) Solenoid Failed On (Turns On TCIL)  
**P1744** Torque Converter Clutch (TCC) System Mechanically Stuck In Off Position  
**P1746** Electronic Pressure Control (EPC) Solenoid Open Circuit (Low Input)  
**P1747** Electronic Pressure Control (EPC) Solenoid Short Circuit (High Input)  
**P1748** Electronic Pressure Control (EPC) Malfunction  
**P1749** Electronic Pressure Control (EPC) Solenoid Failed Low

**P1751** Shift Solenoid#1 (SS1) Performance  
**P1754** Coast Clutch Solenoid (CCS) Circuit Malfunction  
**P1756** Shift Solenoid#2 (SS2) Performance  
**P1760** Overrun Clutch SN  
**P1761** Shift Solenoid #(SS2) Performance  
**P1762** Transmission Malfunction  
**P1765** 3 —2 Timing Solenoid Malfunction (2.5L Only)  
**P1779** TCIL Circuit Malfunction  
**P1780** Transmission Control Switch (TCS) Circuit Out Of Self-Test Range  
**P1783** Transmission Over Temperature Condition  
**P1784** Transmission Malfunction  
**P1785** Transmission Malfunction  
**P1786** Transmission Malfunction  
**P1787** Transmission Malfunction  
**P1788** 3 —2 Timing/Coast Clutch Solenoid (3 —2/CCS) Circuit Open  
**P1789** 3 —2 Timing/Coast Clutch Solenoid (3 —2/CCS) Circuit Shorted  
**P1792** Idle (IDL) Switch (Closed Throttle Position Switch) Malfunction  
**P1794** Loss Of Battery Voltage Input  
**P1797** Neutral Switch Circuit Malfunction  
**P1900** Cooling Fan  
**U1021** SCP Indicating The Lack Of Air Conditioning (A/C) Clutch Status Response  
**U1039** Vehicle Speed Signal (VSS) Missing Or Incorrect  
**U1051** Brake Switch Signal Missing Or Incorrect  
**U1073** SCP Indicating The Lack Of Engine Coolant Fan Status Response  
**U1131** SCP Indicating The Lack Of Fuel Pump Status Response  
**U1135** SCP Indicating The Ignition Switch Signal Missing Or Incorrect  
**U1256** SCP Indicating A Communications Error  
**U1451** Lack Of Response From Passive Anti-Theft System (PATS) Module —Engine Disabled

## VACUUM DIAGRAMS

Following are vacuum diagrams for most of the engine and emissions package combinations covered by this manual. Because vacuum circuits will vary based on various engine and vehicle options, always refer first to the vehicle emission control

information label, if present. Should the label be missing, or should vehicle be equipped with a different engine from the vehicle's original equipment, refer to the diagrams below for the same or similar configuration.

If you wish to obtain a replacement emissions label, most manufacturers make the labels available for purchase. The labels can usually be ordered from a local dealer.




Fig. 83 1988-1990 Continental typical vacuum diagram—3.8L engine




Fig. 84 1988-1990 Mark VII typical vacuum diagram—5.0L engine




Fig. 85 1988-1990 Town Car typical vacuum diagram—5.0L engine (1 of 2)




Fig. 86 1988-1990 Town Car typical vacuum diagram—5.0L engine (2 of 2)







Fig. 87 1991 Town Car typical vacuum diagram—4.6L engine (1 of 2)



# 4-30 DRIVEABILITY AND EMISSIONS CONTROLS






Fig. 91 1992 Town Car typical vacuum diagram—4.6L engine (1 of 2)




Fig. 92 1992 Town Car typical vacuum diagram—4.6L engine (2 of 2)




Fig. 93 1992 Mark VII typical vacuum diagram—5.0L engine






Fig. 94 1993 Town Car typical vacuum diagram—4.6L engine (1 of 2)





93144V02

Fig. 95 1993 Town Car typical vacuum diagram—4.6L engine (2 of 2)



93144V03

Fig. 96 1993 Continental typical vacuum diagram—3.8L engine

# 4-34 DRIVEABILITY AND EMISSIONS CONTROLS




Fig. 97 1993 Mark VIII typical vacuum diagram—4.6L engine (1 of 2)

93144V04




Fig. 98 1993 Mark VIII typical vacuum diagram—4.6L engine (2 of 2)

93144V05




Fig. 99 1994 Town Car typical vacuum diagram—4.6L engine (1 of 2)






Fig. 100 1994 Town Car typical vacuum diagram—4.6L engine (2 of 2)

# 4-36 DRIVEABILITY AND EMISSIONS CONTROLS



93144V08


Fig. 101 1994 Continental typical vacuum diagram—3.8L engine



93144V09


Fig. 102 1994 Mark VIII typical vacuum diagram—4.6L engine (1 of 3)





93144V10

Fig. 103 1994 Mark VIII typical vacuum diagram—4.6L engine (2 of 3)



93144V11

Fig. 104 1994 Mark VIII typical vacuum diagram—4.6L engine (3 of 3)

# 4-38 DRIVEABILITY AND EMISSIONS CONTROLS




Fig. 105 1995 Town Car typical vacuum diagram—4.6L engine (1 of 2)

93144V12






Fig. 106 1995 Town Car typical vacuum diagram—4.6L engine (2 of 2)

93144V13



93144V14


Fig. 107 1995 Continental typical vacuum diagram—4.6L engine




93144V15

Fig. 108 1995 Mark VIII typical vacuum diagram—4.6L engine (1 of 3)

# 4-40 DRIVEABILITY AND EMISSIONS CONTROLS




93144V16




93144V17






93144V18

Fig. 111 1996 Town Car typical vacuum diagram—4.6L engine (1 of 2)




93144V19

Fig. 112 1996 Town Car typical vacuum diagram—4.6L engine (2 of 2)




93144V20

Fig. 113 1996 Continental typical vacuum diagram—4.6L engine




93144V21

Fig. 114 1996 Mark VIII typical vacuum diagram—4.6L engine (1 of 3)



93144V22

Fig. 115 1996 Mark VIII typical vacuum diagram—4.6L engine (2 of 3)



93144V23

Fig. 116 1996 Mark VIII typical vacuum diagram—4.6L engine (3 of 3)

# 4-44 DRIVEABILITY AND EMISSIONS CONTROLS




Fig. 117 1997 Town Car typical vacuum diagram—4.6L engine




Fig. 118 1997 Continental typical vacuum diagram—4.6L engine






Fig. 119 1997 Mark VIII typical vacuum diagram—4.6L engine






Fig. 120 1998 Mark VIII typical vacuum diagram—4.6L engine

# 4-46 DRIVEABILITY AND EMISSIONS CONTROLS



93144V27

Fig. 121 1998-00 Town Car typical vacuum diagram—4.6L engine



93144V28

Fig. 122 1998-00 Continental typical vacuum diagram—4.6L engine

## MANUFACTURER RECOMMENDED SEVERE MAINTENANCE INTERVALS

### VEHICLE MAINTENANCE INTERVAL

		Miles (x1000)	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	60	
		km (x1000)	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	
Component	Type of Service																						
Engine oil and filter	Replace	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Tires	Rotate		✓		✓		✓		✓		✓		✓		✓		✓		✓		✓		✓
Air cleaner	Replace											✓											✓
Spark plugs ①	Replace																						✓
Drive belt	Inspect																						✓
Cooling system	Inspect						✓					✓					✓						✓
Coolant	Replace																	✓					
PCV valve	Replace																						✓
Automatic transmission fluid & filter	Replace								✓							✓							
Exhaust heat shields	Inspect											✓											✓
Brake linings and drums	Inspect			✓			✓			✓			✓		✓		✓			✓			
Brake pads and rotors	Inspect			✓			✓			✓			✓		✓		✓			✓			
Fuel filter	Replace						✓					✓											
Lubricate suspension	Inspect						✓					✓					✓						✓
Brake line hoses and connections	Inspect						✓					✓					✓						✓
Front suspension	Inspect						✓					✓					✓						✓
Bolts and nuts on chassis body	Inspect						✓					✓					✓						✓
Steering linkage operation	Inspect						✓					✓					✓						✓

Perform maintenance at the same intervals for mileage beyond that on this chart

Follow the severe service interval schedule if the vehicle is driven in the following conditions:

- towing a trailer or using a car-top carrier
- operating in severe dust conditions
- extensive idling such as a police car, taxi, or delivery service
- short trips of less than 10 miles when outside temperatures remain below 0°F (-18°C)

① Except on the 4.6L engines. Replace every 100,000 miles on the 4.6L engines.