

## DIAGNOSIS AND TESTING (Continued)

(Continued)

**PINPOINT TEST B**  
**TEMPERATURE GAUGE INOPERATIVE — POINTER DOES NOT MOVE**

TEST STEP	RESULT	ACTION TO TAKE
<b>B1</b> VERIFY CONDITION		
<ul style="list-style-type: none"> <li>Observe gauge performance.</li> <li>Does gauge pointer move?</li> </ul>	Yes	GO to C1 for temperature gauge.
	No	GO to B2.
<b>B2</b> VERIFY CLUSTER PERFORMANCE		
<ul style="list-style-type: none"> <li>With the ignition ON, observe the other gauges and warning indicators for proper operation.</li> <li>Do other gauges and warning indicators operate properly?</li> </ul>	Yes	GO to D1.
	No	GO to C1.

TK16967B

**PINPOINT TEST C**  
**TEMPERATURE GAUGE INOPERATIVE**

TEST STEP	RESULT	ACTION TO TAKE
<b>C1</b> VERIFY POWER AT FUSE PANEL		
<ul style="list-style-type: none"> <li>Using Rotunda Digital Volt-Ohmmeter 007-00001 or equivalent verify system voltage at load side of warning indicator fuse.</li> <li>Is system voltage present at load side of fuse?</li> </ul>	Yes	GO to D1.
	No	GO to C2.
<b>C2</b> VERIFY POWER AT FUSE PANEL		
<ul style="list-style-type: none"> <li>Using Rotunda Digital Volt-Ohmmeter 007-00001 or equivalent verify system voltage at feed side of warning indicator fuse.</li> <li>Is system voltage present at feed side of fuse?</li> </ul>	Yes	REPLACE fuse. GO to B1.
	No	SERVICE wiring to fuse panel. GO to B1.

TK16972B

**PINPOINT TEST D**  
**TEMPERATURE GAUGE INOPERATIVE**

TEST STEP	RESULT	ACTION TO TAKE
<b>D1</b> VERIFY POWER AT CLUSTER		
<ul style="list-style-type: none"> <li>Partially remove cluster from IP. Using Rotunda Digital Volt-Ohmmeter 007-00001 or equivalent verify system voltage at cluster connector and/or gauge terminal.</li> <li>Inspect cluster connector for damage.</li> <li>Is system voltage present at cluster connector and/or gauge terminal?</li> </ul>	Yes	GO to D2.
	No	SERVICE as required. GO to B1.
<b>D2</b> VERIFY GROUND CIRCUITRY AT CLUSTER		
<ul style="list-style-type: none"> <li>Using Rotunda Digital Volt-Ohmmeter 007-00001 or equivalent check continuity of cluster and gauge ground circuitry.</li> <li>Is ground circuitry OK?</li> </ul>	Yes	GO to E1 for temperature gauge.
	No	SERVICE as required. GO to B1.

TK17129A

**PINPOINT TEST E**  
**TEMPERATURE GAUGE INACCURATE**

TEST STEP	RESULT	ACTION TO TAKE
<b>E1</b> TEST SENDER CIRCUIT AT LOW		
<ul style="list-style-type: none"> <li>Insert Rotunda Instrument Gauge, System Tester 021-00055 or equivalent. Disconnect connector at sender and connect tester to cluster side of connector. Set to 74 ohms.</li> <li>Does gauge read 'C'?</li> </ul>	Yes	GO to E2.
	No	GO to E3.
<b>E2</b> TEST SENDER CIRCUIT AT HIGH		
<ul style="list-style-type: none"> <li>Set Gauge System Tester to 10 ohms.</li> <li>Does gauge read 'H'?</li> </ul>	Yes	REPLACE sender.
	No	GO to E3.