TIRE STOWAGE (Continued)

3. Pull front of cover out slightly and remove cover by sliding it toward front of vehicle.
4. Lift out spare tire, jack and wheel lug nut wrench.

Tire, Temporary Spare

WARNING: IF YOU USE THE TEMPORARY SPARE TIRE CONTINUOUSLY OR DO NOT FOLLOW THESE PRECAUTIONS, THE TIRE COULD FAIL, CAUSING YOU TO LOSE CONTROL OF THE VEHICLE AND POSSIBLY INJURE YOURSELF OR OTHERS.

The temporary spare tire is smaller than conventional tires and designed for emergency use only. The spare tire is labeled with TEMPORARY USE ONLY. Replace temporary spare as soon as possible.

NOTE: Extended use of other than conventional spare tires on a Traction-Lok rear axle could result in a permanent reduction in effectiveness. This loss of effectiveness does not affect normal driving and should not be noticeable to the driver.

When using a temporary spare tire, observe the following precautions:

- **Never** drive faster than 80 km/h (50 mph) under any circumstances.
- **Never** exceed the maximum vehicle load rating listed on tire decal.
- **Never** tow a trailer.
- **Never** use tire chains on this tire.
- **Never** service temporary spare tire or remove it from wheel.
- **Never** use wheel for any other type of vehicle.
- **Never** drive through automatic car wash with temporary tire. Temporary spare tire is smaller than a conventional tire, which reduces ground clearance and could cause vehicle to get caught in the rails causing damage.

Tire, Conventional Spare

The conventional spare tire supplied with the vehicle can be used as a spare or regular tire. This tire is identical to the tires supplied with the vehicle.

NOTE: Spare tire wheel may differ if vehicle has styled wheels.