

REMOVAL AND INSTALLATION (Continued)

4. Disengage two J-retainers from each other at the bottom of the seat back.
5. Pull cover up the back (inside out) exposing hog rings.
6. Cut wires retaining hog rings. Remove trim cover. Remove retaining wires from their listings.
7. Remove pad assembly, if necessary.

Installation

1. Install head restraint retaining clips, one each guide rod sleeve.
2. Install pad, if removed.
3. With the exception of the top portion, approximately 20cm (8 inches), turn the new trim cover inside out.

4. Position trim cover to pad assembly. Work trim cover down until horizontal tiedown wire is aligned with its retaining wire in pad assembly. Install tiedown wire in the listing. Secure tiedown wire to pad assembly with hog rings.
5. Position remaining portion of trim cover to pad assembly.
6. Engage two J-retainers to each other to close trim cover.
7. Install head restraint assembly as outlined.
8. Install seat back assembly to recliner. Tighten retaining bolts to 44-60 N·m (33-44 lb-ft).
9. Install seat and track assembly. Tighten retaining bolts to 12-24 N·m (9-17 lb-ft), inboard nut to 60-90 N·m (44-66 lb-ft) and outboard nut to 12-24 N·m (9-17 lb-ft).
10. Check seat tracks for proper operation.

