

LOCATION (Continued)

Wagon Without Auxiliary Rear Seat—All

On all Wagon models, two (one each side) steel U-shaped load floor anchors located on the forward auxiliary floor trim panel have been provided for attachment of the child safety tethers. The tether anchors are easily accessed by inserting a small screwdriver under the attachment anchor covers and prying them off the anchors.

WARNING: IF THE ANCHOR BOLTS ARE EVER REMOVED, THE HOLE(S) IN THE FLOOR MUST BE SEALED TO PREVENT THE POSSIBILITY OF FUMES ENTERING THE PASSENGER COMPARTMENT.

