

REMOVAL AND INSTALLATION (Continued)

REMOVAL AND INSTALLATION (Continued)

10. Attach sway bar links.

11. Raise hoist until subframe contacts body.

12. Install subframe retaining bolts.

13. Install gear-to-subframe nuts and tighten to 115-135 N·m (85-100 lb-ft).

14. Attach exhaust pipe to catalytic converter.

