



PRY FRONT WHEEL
DRIVE SHAFT
FROM TRANSAXLE