


**UNDERHOOD COMPONENT MAINTENANCE LOCATIONS—5.0L ENGINE**

- |                          |                                       |                                  |
|--------------------------|---------------------------------------|----------------------------------|
| 1. Battery               | 6. PCV valve                          | 11. Radiator cap                 |
| 2. Air Cleaner           | 7. Spark plug wires                   | 12. Power steering fill cap      |
| 3. Radiator hose (Upper) | 8. Accessory drive (Serpentine belt)  | 13. Oil fill cap                 |
| 4. Master cylinder       | 9. Coolant tank                       | 14. Oil dipstick                 |
| 5. Transmission dipstick | 10. Windshield washer fluid reservoir | 15. Spark plugs (4 on each side) |



981MF3