

Function	Trade number
Exterior lights	
Tail lamp, brakelamp, turn lamp	3157
Backup lamp	3156
Side marker lamp	194
Front park, turn lamp	3157NA**
Headlamp—Aero	9004*
Cornering lamp	3156
Fog lamp	H-2
License plate lamp	168
High mounted brakelamp	912
Interior lights	
Luggage compartment lamp	912
Visor vanity lamp	168
Door courtesy lamp	904
Engine compartment lamp	912
Front overhead map/courtesy lamp	912
Reading lamp — rear	912
Dual floorwell lamp	906
Ashtray lamp (Armrest)	1893
Instrument panel lights	
Clove box	194
Instrument courtesy lamps	89
Warning lights (all)	37
Radio illumination	*
Speedometer illumination	168
"PRN" D1" bulb	168
Trip/finder [®] illumination	194
High beam indicator	37
Turn signal indicator	194
Climate control panel lights	37
Instrument panel lights	194
Headlamp nomenclature	37
Autolamp nomenclature	1816
Ashtray lamp (console)	1815
Cigarette lighter lamp	1445

*Use only original equipment bulbs or equivalent, if you do not, it may result in false warning or no headlamp burnout warning from the message center.
 **NA means Natural Amber
 • Refer bulb replacement to a Ford authorized radio service center.

93146G01

**Light bulb application chart—1988-92
Mark VII.**

Function	Trade number
Exterior lights	
Tail lamp, brakelamp, turn lamp	3157
Backup lamp	3156
Side marker lamp - front	194 NA**
Front park, turn lamp	3157NA**
Headlamp (hi & lo)	9004*
Cornering lamp	2456
License plate lamp	194
High-mounted brakelamp	912
Interior lights	
Luggage compartment lamp	906
Map lamp	211-2
Visor vanity lamp	168
Door courtesy lamp	168
Engine compartment lamp	906
Dual floorwell lamps	906
Armrest ashtray lamp	161
Instrument panel lights	
Clove compartment	194
Warning lights (all)	37
Radio illumination	*
Compact disc illumination (opt.)	••
High beam indicator	194
Turn signal indicator	194
Low fuel warning light	194
I/P ashtray lamp	161
Cigarette lighter lamp	1445
Instrument panel lights	194
Headlamp nomenclature	1816
Autolamp nomenclature	1816
Automatic climate control	161
"PRNDL"	37

*Use only original equipment bulbs or equivalent, if you do not, it may result in false warning or no headlamp burnout warning from the message center.
 **NA means Natural Amber
 • Refer bulb replacement to Ford authorized radio service center
 •• Refer bulb replacement to manufacturer (Sony)

93146G02

**Light bulb application chart—1988-90
Town Car**

Function	Trade number
Exterior illumination	
Backup lamp	3156
Cornering lamp	3156
Headlamp	9004
High-mount brakelamp	921
License plate lamp	168
Luggage compartment lamp	912
Side marker—front lamp	194
Side marker—rear lamp	168
Turn signal and park lamp—front	3157NA***
Turn signal, stoplamp and taillamp—rear	3157NA***
Under hood lamp	912
Instrument panel	
EATC	*
Air bag readiness light	37
Anti-lock warning lamp	37
Anti-theft warning lamp	37
Ash receptacle	1445
Clock	(*)
Cluster illumination	*
Cluster control button	37
Compact disc player	••
Glove compartment	194
Headlamp switch nomenclature	37
Heated windshield switch nomenclature	37
Message center control buttons	*
Rear window defrost switch nomenclature	37
Radio	••
Warning lights (cluster)	37

*Refer bulb replacement to dealer.
 **Refer bulb replacement to a Ford authorized radio service center.
 ***NA means natural amber.

93146G08

**Light bulb application chart—1988-92
Continental**

Function	Trade number
Exterior lights	
Tail lamp, brakelamp, turn lamp	3157
Backup lamp	3156
Side marker lamp - front	194 NA**
Front park, turn lamp	3157NA**
Headlamp (hi & lo)	9004
Cornering lamp	3156
High-mounted brakelamp	194
Interior lights	912
Luggage compartment lamp	906
Map lamp	211-2
Visor vanity lamp	168
Door courtesy lamp	904
Engine compartment lamp	906
Dual floorwell lamps	906
Instrument panel lights	
Glove compartment	194
Rear window defroster switch***	
Heated windshield switch***	
Fuel door release switch***	
Warning lights (all) (std.)	194
Radio illumination	*
Compact disc illumination (opt.)	••
High beam indicator (std.)	194
Turn signal indicator (std.)	194
Low fuel warning light (std.)	194
I/P ashtray lamp	161
Cigarette lighter lamp	1445
Instrument panel lights	194
Headlamp nomenclature	1816
Autolamp nomenclature	1816
Automatic climate control	161
"PRNDL" (std./elect.)	194/37

**NA means Natural Amber
 ***Refer bulb replacement to a Ford or Lincoln-Mercury dealer.
 • Refer bulb replacement to Ford authorized radio service center
 •• Refer bulb replacement to manufacturer (Sony)

93146G06

**Light bulb application chart—1991-92
Town Car**

Function	Trade number
Exterior illumination	
Backup lamp	3156
Cornering lamp	3156
Headlamp	9004
High-mount brakelamp	921
License plate lamp	168
Luggage compartment lamp	912
Side marker—front lamp	194
Side marker—rear lamp	168
Turn signal and park lamp—front	3157NA***
Turn signal, stoplamp and taillamp—rear	3157NA***
Under hood lamp	912
Instrument panel	
Electronic automatic temperature control	*
Air bag readiness light	37
Anti-lock warning lamp	37
Anti-theft warning lamp	37
Ash receptacle	1445
Clock	(*)
Cluster illumination	*
Cluster control button	37
Compact disc player	••
Glove compartment	194
Headlamp switch nomenclature	37
Message center control buttons	*
"PRNDL" bulb (floor console)	194
Rear window defrost switch nomenclature	37
Radio	••
Warning lights (cluster)	37

*Refer bulb replacement to dealer.
 **Refer bulb replacement to a Ford authorized radio service center.
 ***NA means natural amber.

93146G03

**Light bulb application chart—1993-00
Continental**

Function	Trade number
Exterior lights	
Tail lamp, brakelamp, turn lamp	3157
Backup lamp	3156
Side marker lamp - front	194 NA**
Front park, turn lamp	3157NA**
Headlamp (hi & lo)	9004
Cornering lamp	3156
License plate lamp	194
High-mounted brakelamp	912
Interior lights	
Luggage compartment lamp	906
Map lamp	211-2
Visor vanity lamp	168
Door courtesy lamp	904
Engine compartment lamp	906
Instrument panel lights	
Glove compartment	194
Rear window defroster switch***	
Heated windshield switch***	
Fuel door release switch***	
Warning lights (all) (std.)	194
Radio illumination	*
Compact disc illumination (opt.)	••
High beam indicator (std.)	194
Turn signal indicator (std.)	194
Low fuel warning light (std.)	194
I/P ashtray lamp	161
Cigarette lighter lamp	1445
Instrument panel lights	194
Headlamp nomenclature	1816
Autolamp nomenclature	1816
Automatic climate control	161
"PRNDL" (std./elect.)	194/37

**NA means Natural Amber
 ***Refer bulb replacement to a Ford or Lincoln-Mercury dealer.
 • Refer bulb replacement to Ford authorized radio service center
 •• Refer bulb replacement to manufacturer (Sony)

93146G04

**Light bulb application chart—1993-00
Town Car**