


MEGA-FUSE	AMPS	CIRCUITS PROTECTED
1	175	Generator/Voltage Regulator
2	40	Blower Motor Relay
3	60	Engines Cooling Fans
4	60	Air Suspension
5	60	Anti-Lock Brake Control Module, ABS E/MC and Fill Connector
6	60	IP Fuse Panel
7	30	PCM Power
8	40	Rear Window Defrost Control
9	40	Driver Window
10	20	Thermactor Pump
11	40	Ignition Switch
12	40	Ignition Switch
13	30	Driver's Seat Module
14	30	Passenger's Seat Module

MEGA-FUSE	AMPS	CIRCUITS PROTECTED
15	10A	Air Bag
16	20A	Horns
17	15A	Hi Beam
18	50A	Front Passenger Window
19	10A	PCM CAM
20	10A	ALT SENSE
21	50A	Rear Passenger Window
22	30A	Air Suspension

9314637

The engine compartment fuse box locations—1997 Continental



FUSE	AMPS	CIRCUITS PROTECTED
1	10	Lighting Control Module (LCM), Left Headlamp, DRL
2	10	Lighting Control Module (LCM), Left Headlamp, DRL
3	10	Lighting Control Module (LCM), Left Headlamp, DRL
4	10	Lighting Control Module (LCM), Left Headlamp, DRL
5	5	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
6	15	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
7	15	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
8	15	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
9	10	ABS E/MC and Fill Connector, ABS Control Module
10	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
11	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
12	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
13	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
14	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
15	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
16	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
17	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM
18	10	Multi-Function Switch, Connecting Lamps, High Beam and Turn Signal Input to LCM

9314636

The interior fuse box locations—1997 Continental