

**AUTOMATIC TRANSMISSION 7-2**

FLUID PAN AND FILTER SERVICE 7-2

REMOVAL & INSTALLATION 7-2

NEUTRAL SAFETY SWITCH 7-2

REMOVAL & INSTALLATION 7-2

ADJUSTMENT 7-2

MANUAL LEVER POSITION (MLP)

SENSOR/TRANSMISSION RANGE (TR)

SENSOR 7-2

REMOVAL & INSTALLATION 7-2

ADJUSTMENT 7-2

EXTENSION HOUSING SEAL 7-3

REMOVAL & INSTALLATION 7-3

AUTOMATIC TRANSMISSION ASSEMBLY

7-3

REMOVAL & INSTALLATION 7-3

**AUTOMATIC TRANSAXLE 7-4**

FLUID PAN 7-4

REMOVAL & INSTALLATION 7-4

ADJUSTMENTS 7-4

SHIFT LINKAGE 7-4

THROTTLE CABLE 7-4

THROTTLE VALVE CONTROL LINKAGE

7-4

NEUTRAL SAFETY SWITCH 7-4

REMOVAL & INSTALLATION 7-4

TRANSAXLE 7-5

REMOVAL & INSTALLATION 7-5

HALFSHAFTS 7-6

REMOVAL & INSTALLATION 7-7

**DRIVELINE 7-9**

DRIVESHAFT AND U-JOINTS 7-9

REMOVAL & INSTALLATION 7-9

U-JOINT REPLACEMENT 7-10

AXLE SHAFT, BEARING AND SEAL 7-10

REMOVAL & INSTALLATION 7-10

PINION SEAL 7-12

REMOVAL & INSTALLATION 7-12

AXLE HOUSING 7-12

REMOVAL & INSTALLATION 7-12

**SPECIFICATION CHARTS**

AXODE (AX4S) TORQUE

SPECIFICATIONS 7-13

AX4N TORQUE SPECIFICATIONS 7-14

AODE TORQUE SPECIFICATIONS 7-14

# 7

## DRIVE TRAIN

AUTOMATIC TRANSMISSION 7-2

AUTOMATIC TRANSAXLE 7-4

DRIVELINE 7-9