


Page

The third set of numbers indicate the Page in each Section.



How to Find Material in This Manual

1. Locate the Group number in the Table of Contents. **If you are not sure which Section contains the information you need, look up the component/system in the alphabetical index located in the back of this manual.**
2. Locate the Section number by using the Group index located at the beginning of each Group.
3. Locate the specific Page by using the Section index at the beginning of each Section.

How to Use Each Section

Each Section has a standard organization that consists of the following information:

Vehicle Application

Identifies the product (vehicle, model, engine, transmission, etc.) that the section applies to:

- Probe GT
- Aerostar and Ranger with integral carrier and 7.5 ring gear

Description and Operation

Describes how the component or system works.

Diagnosis and Testing

Identifies how to pinpoint problems.