


REMOVAL AND INSTALLATION (Continued)

5. To install, reverse Removal procedure. Replace any bent or damaged push pins.




R4366-D

Trim Panel, Luggage Compartment

Remove and install luggage compartment trim as shown.

LUGGAGE COMPARTMENT DECK LID SCUFF PLATE 42624



SABLE SHOWN TAURUS TYPICAL

R7601-A