


**REMOVAL AND INSTALLATION (Continued)**

21. Remove one screw retaining instrument panel to RH side.



U-NUT  
N800854-S52  
1 REQ'D EACH SIDE

SCREW  
N606676-S55  
1 REQ'D EACH SIDE  
TIGHTEN TO  
9-14 N·m  
(80-123 LB-IN)

R7617-A