


REMOVAL AND INSTALLATION (Continued)

(Continued)



K16854-A

Item	Part Number	Description
1	6C625AA	Indicator Assy
2	14B193A	Relay Assy Horn
3	14A323A	Bracket Assy Relay Panel
4	17D539AB	Wiper Control Module
5	5404304	Panel Assy Instrument

Item	Part Number	Description
6	N803876	Screw (2 Req'd)
7	N803875-S36	Screw OK
8	10D840A	Chime Assy
9	18C641A	Rear Window Defroster Timer (Sable)
10	14B193A	Relay Assy Fog Lamps (SHO)


(Continued)

**Wiper Switch, Front**  
Refer to Section 11-05.

**Wiper / Washer Switch, Rear**  
**Removal and Installation**

1. Remove cluster opening finish panel. Refer to Section 01-12.
2. Disconnect wiring connector from rear washer switch.
3. Remove washer switch from cluster opening finish panel.
4. To install, reverse Removal procedure.

**Taurus**



K16738-B