


DIAGNOSIS AND TESTING (Continued)

(Continued) DIAGNOSIS AND TESTING

CHARGING SYSTEM VOLTAGE

| PIN No. | 9.0 | 9.5 | 10.0 | 10.5 | 11.0 | 11.5 | 12.0 | 12.5 | 13.0 | 13.5 | 14.0 | 14.5 | 15.0 | 15.5 | 16.0 |
|---------|-----|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|
| 11 | 2.3 | 2.4 | 2.5 | 2.7 | 2.8 | 3.0 | 3.1 | 3.2 | 3.4 | 3.5 | 3.7 | 3.8 | 4.0 | 4.1 | 4.3 |
| 12 | 2.3 | 2.4 | 2.5 | 2.7 | 2.8 | 3.0 | 3.1 | 3.2 | 3.4 | 3.5 | 3.7 | 3.8 | 4.0 | 4.1 | 4.3 |

Electrical Schematic—Diagnostic Trouble Code 22



R8120-A