

DIAGNOSIS AND TESTING

DESCRIPTION

GROUP ENGINE 03

(6000 & 9000)

SECTION TITLE	PAGE
AIR INTAKE SYSTEM	03-12-1
DRIVE BELTS, ACCESSORY	03-05-1
ELECTRONIC IGNITION (EI) HIGH DATA RATE SYSTEM—FLEX FUEL	03-07c-1
ENGINE COOLING	03-03-1
ENGINE—SERVICE	03-001
ENGINE, 3.0L	03-01A-1
ENGINE, 3.0L/3.2L SHO	03-01B-1
ENGINE, 3.8L	03-01C-1

SECTION TITLE	PAGE
IGNITION, DISTRIBUTOR	03-07A-1
IGNITION, ELECTRONIC	03-07B-1
EVAPORATIVE EMISSIONS	03-13-1
FUEL CHARGING AND CONTROLS—3.0L	03-04A-1
FUEL CHARGING AND CONTROLS—3.0L/3.2L SHO	03-04B-1
FUEL CHARGING AND CONTROLS—3.8L	03-04C-1
STARTING SYSTEM	03-06-1

SECTION 03-00 Engine—Service

SUBJECT	PAGE
ADJUSTMENTS	
Valve Clearance	03-00-11
DESCRIPTION	
Engine Identification	03-00-2
Exhaust Emission Control System	03-00-2
DIAGNOSIS AND TESTING	
3.0L and 3.8L Engine	03-00-7
Static Engine Off Valve Train Analysis	03-00-7
3.0L/3.2L SHO Engine	03-00-10
Dynamic Valve Train Analysis	03-00-11
Flywheel Runout (Manual Transaxle)	03-00-10
Static Engine Off Valve Train Analysis (Cylinder Head Cover Removed)	03-00-11
Closed-Type Positive Crankcase Ventilation (PCV) System	03-00-3
Compression Tests	03-00-4
Dynamic Valve Train Analysis	03-00-7
Camshaft End Play	03-00-9
Camshaft Lobe Lift	03-00-8
Crankshaft End Play	03-00-10
Hydraulic Tappet/Lash Adjuster	03-00-8
Engine Oil Leaks	03-00-3
Excessive Engine Oil Consumption	03-00-5
Fluorescent Oil Additive Method	03-00-3
Possible Leakage Points	03-00-3
Pressure Method	03-00-3

SUBJECT	PAGE
OVERHAUL	
Camshaft	03-00-21
Connecting Rods	03-00-20
Core Plugs	03-00-15
Crankshaft	03-00-17
Cylinder Block	03-00-13
Cylinder Heads	03-00-23
Exhaust Manifolds	03-00-30
Fitting Main or Connecting Rod Bearings with Plastigage	03-00-17
Flywheel	03-00-30
Hydraulic Tappets/Hydraulic Roller Tappets	03-00-21
Intake Manifolds	03-00-30
Journals, Refinishing	03-00-18
Main and Connecting Rod Bearings	03-00-16
Oil Pan	03-00-23
Oil Pump	03-00-22
Pistons, Pins and Rings	03-00-18
Push Rods	03-00-29
Service Limit Specifications	03-00-13
Valve Guides, Reaming—3.0L/3.2L SHO	03-00-26
Valve Rocker Arm	03-00-29
Valve Seats, Refacing	03-00-28
Valves, Refacing	03-00-27
SPECIAL SERVICE TOOLS	03-00-30
VEHICLE APPLICATION	03-00-1

VEHICLE APPLICATION

Taurus/Sable and Taurus 3.0L/3.2L SHO.

Possible Leakage Points

Examine the following areas for oil leakage: