

## DESCRIPTION AND OPERATION (Continued)

(Continued)

Item	Part Number	Description
1	—	Frame
2	N805219-S151	Bolt (4 Req'd)
3A	N8044525-S150	Nut (4 Req'd)
4	5A950	Tension Strut (2 Req'd)
5	N802855-S36	Washer (2 Req'd)
6	5K897	Insulator (4 Req'd)
7	N801335-S36	Washer (2 Req'd)
8B	N620484-S151	Nut (4 Req'd)
9	5K743	Arm Assy (2 Req'd)
10	N804001-S100	Washer (4 Req'd)
11C	N800937-S160	Nut
12D	N804608-S150	Nut
13E	N801310-S100	Nut (6 Req'd)
14F	N800280-S7	Nut (4 Req'd)
15	N802100-S36M	Washer (4 Req'd)
16	5493	Insulator (8 Req'd)
17	5A772	Stabilizer Bar
18	4A037	Insulator (2 Req'd)
19G	N804637-S56	Bolt (2 Req'd)
20	4AD47	U-Bracket (2 Req'd)
21H	N80194-2-S100	Bolt (2 Req'd)
22	4A493 Assy LH 4A494 Assy RH	Spindle
23	5664	Link (2 Req'd)
24	5K617	Insulator (2 Req'd)
25	18A085	Jounce Bumper (2 Req'd)
26	5560	Spring (2 Req'd)
27	N804232-S100	Washer (2 Req'd Some Vehicles)

(Continued)

Item	Part Number	Description
28	N804232-S100	Washer (2 Req'd)
29	5K751	Adjusting Cam (2 Req'd)
30	5K743	Arm Assy
31	5A669	Rear Spring Damper (4 Req'd)
32	5A545	Rear Spring Insulator Retainer
33	10080	Spring Seat Pocket
34	5K742	Arm Assy (2 Req'd)
35	N804001	Washer
36	N804348-S150	Bolt (4 Req'd)
37	N802855	Washer (2 Req'd)
38	N801335	Washer (2 Req'd)
39	N804002-S36	Washer (2 Req'd)
40	5A959	Insulator (4 Req'd)
41	N804003-S36	Washer (2 Req'd)
A		Tighten to 68-92 N·m (50-67 Lb-Ft)
B		Tighten to 47-63 N·m (35-46 Lb-Ft)
C		Tighten to 59.5-80.5 N·m (44-59 Lb-Ft)
D		Tighten to 53-72 N·m (40-53 Lb-Ft)
E		Tighten to 25-34 N·m (19-25 Lb-Ft)
F		Tighten to 7-9.5 N·m (5-7 Lb-Ft)
G		Tighten to 34-46 N·m (25-33 Lb-Ft)
H		Tighten to 68-92 N·m (50-67 Lb-Ft)

**Wheel Assembly**

Each rear wheel is bolted to a bearing and hub assembly. The bearing and hub assembly is lubricated for life and has integral seals.

A nut and washer assembly retains the bearing and hub assembly to the spindle.