

REMOVAL AND INSTALLATION (Continued)

(Continued)

Item	Part Number	Description
1	5G250	Converter and Pipe Assy
2	5G203	Resonator
3	5G213	Exhaust and Muffler Assy
4A	N802068-S2	Nut
5	—	Transmission Mounting Stud
6B	N606705-S2	Bolt
7	N807325-S2	Nut
8	—	Exhaust Manifold
9A	N620482-S2	Nut (4 Req'd)
10	N806534-S	Stud (4 Req'd)
11	N802641-S2	Nut (2 Req'd)
12	5E241	Gasket
13A	N806777-S2	Bolt (2 Req'd)

Item	Part Number	Description
14	5F262	Insulator Hanger
15	5291	Bracket
16C	N802324-S2	Bolt (4 Req'd)
17	—	Body
18	5A235	Bracket
19D	N606703-S2	Bolt (2 Req'd)
20C	N802324-S2	Bolt (2 Req'd)
A		Tighten to 34-46 N·m (26-33 Lb-Ft)
B		Tighten to 29.7-40.3 N·m (22-30 Lb-Ft)
C		Tighten to 14.8-20.2 N·m (11-15 Lb-Ft)
D		Tighten to 35-55 N·m (24-41 Lb-Ft)

(Continued)

