

INSTRUMENTATION AND WARNING SYSTEMS

GROUP

13

(10000 & 19000)

SECTION TITLE	PAGE	SECTION TITLE	PAGE
CHARGING SYSTEM GAUGE / WARNING INDICATOR	13-04-1	INSTRUMENT CLUSTER—CONVENTIONAL	13-01B-1
CLOCK	13-07-1	INSTRUMENT CLUSTER—ELECTRONIC	13-01A-1
FUEL GAUGE AND LOW FUEL WARNING GAUGES, WARNING DEVICES, MISCELLANEOUS—ELECTRONIC	13-03-1	SPEEDOMETER / ODOMETER	13-02-1
HORN	13-09-1	TACHOMETER, OIL PRESSURE, COOLANT TEMPERATURE GAUGES / WARNING INDICATORS	13-05-1
	13-06-1		

SECTION 13-01A Instrument Cluster—Electronic

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION AND OPERATION		DIAGNOSIS AND TESTING (Cont'd.)	
Digital Odometer	13-01A-3	Quick Checks	13-01A-5
Digital Speedometer	13-01A-3	Speedometer	13-01A-6
Fuel Computer	13-01A-4	Tachometer Circuit	13-01A-7
Fuel Computer Functions	13-01A-4	Windshield Washer Level	13-01A-8
Fuel Temperature Gauges	13-01A-3	PARTS CROSS-REFERENCE	13-01A-34
Speedometer / Odometer / Tachometer	13-01A-3	REMOVAL AND INSTALLATION	
Switch Module	13-01A-2	Cluster Assembly	13-01A-30
System Scanner	13-01A-5	Electronic Low Fuel Warning Assembly	13-01A-32
Tachometer Bargraph	13-01A-3	Fuel Lines	13-01A-31
DIAGNOSIS AND TESTING		Fuel Pump and Sender Unit Assembly	13-01A-31
Charging System	13-01A-7	Mask Assembly	13-01A-30
Coolant Temperature Sender	13-01A-8	Switch Module	13-01A-31
Dimmer Circuit	13-01A-6	Vehicle Speed Sensor	13-01A-31
Fuel Gauge	13-01A-6	SPECIAL SERVICE TOOLS	13-01A-34
Lamp Out Warning	13-01A-6	SPECIFICATIONS	13-01A-34
Oil Level Warning	13-01A-9	VEHICLE APPLICATION	13-01A-1

VEHICLE APPLICATION

Taurus / Sable.