

REMOVAL AND INSTALLATION (Continued)

Item	Part Number	Description
1	—	Speaker
2	14413	Glove Compartment Lamp
3	14A459	Sleeve Assy
4	—	To In Car Temperature Sensor
5	—	To A/C Heater Switch
6	—	To Radio
7	—	To Control Head
8	—	To Rear Wiper Washer Switch (Wagon Only)
9	—	To Fog Lamp Switch
10	—	To Power Antenna Switch
11	19C734	Sun Load Sensor and Grille
12	14401	Wiring Assy
13	N803875-S2	Screw (2 Req'd)
14	—	To Cluster
15	—	To Steering Column
16	14A320	Wire Assy (With Autolamp)
17	N804234-S36	Screw (2 Req'd)
18	13350	Flasher Assy
19	13730	Bulb Assy (2 Req'd)
20	—	To Parking Brake Switch
21	—	Fuse Panel, Part of 14401 Wiring Harness Assy

(Continued)

Item	Part Number	Description
22	—	To Stoplamp and Anti-Lock Brake Switches
23	10D840	Chime Assy
24	10K910	Lamp Outage Module (Non SHO)
25	16C625	Low Oil Indicator Assy
26	17D539	Wiper Control Module
27	14N089	Horn Relay
28	—	A/C Heater Ground
29	—	To Evaporator Assy
30	N805375-S36MG	Screw
31	—	To Ash Receptacle Wiring
32	14B056	Air Bag Diagnostic Module Monitor Assy
33	19A170	Wire Assy
34	18850	Power Antenna
35	12B577	Power Antenna Module
36	13350	Turn Signal Flasher
37	14401	Connector for Mechanical Cluster
38	13A024	Dimmer Switch
39	—	Passenger Air Bag Assy
40	45A98	Finish Panel
41	11654	Headlamp Switch
42	10K910	Lamp Outage Module
43	14A459	Retainer
44	—	Radio Ground

