

# Glossary

The glossary is a list of technical terms or acronyms and their definitions. It is not intended to be a dictionary of components and their functions. If you desire a detailed description of a specific component, refer to the related Service Manual Group.

**2V:** Two Valve.

**4EAT:** 4-speed Electronic Automatic Transaxle.

**4V:** Four Valve.

**4x4 Low (4x4L):** Indicates that the 4x4 Low range of the transfer case has been selected.

**4x4L:** 4x4 Low.

**A/C:** Air Conditioning.

**A/T:** Automatic Transmission/ Transaxle.

**A4LD:** Automatic 4-speed Lock-up-convertor Drive transmission.

**Absolute Pressure:** The pressure referenced to a perfect vacuum.

**ACC:** Air Conditioning Clutch.

**ACCS:** Air Conditioning Cyclic Switch.

**ACD:** Air Conditioning Demand.

**ACON:** Air Conditioning On.

**ACP:** Air Conditioning Pressure.

**Actuator:** A mechanism for moving or controlling something indirectly instead of by hand.

**Air Conditioning (A/C):** A vehicular accessory system that modifies the passenger compartment air by cooling and drying the air.

**Air Conditioning Clutch (ACC):** Indicates status of the A/C clutch.

**Air Conditioning Cyclic Switch (ACCS):** Indicates status of the A/C cyclic switch.

**Air Conditioning Demand (ACD):** Indicates status of the A/C demand switch.

**Air Conditioning On (ACON):** Indicates status of the A/C system.

**Air Conditioning Pressure (ACP):** Indicates pressure in the A/C system.

**AIR:** Secondary Air Injection.

**AIRB:** Secondary Air Injection Bypass.