


**MAKE SURE THE HUB REMOVER  
ADAPTER IS FULLY THREADED  
ONTO THE HUB STUD AND IS  
POSITIONED OPPOSITE THE  
TWO STUD ADAPTER**

**FRONT HUB  
REPLACER  
T81P-1104-A**

**METRIC HUB REMOVER  
ADAPTERS T83P-1104-BH1**



**TWO STUD ADAPTER  
T86P-1104-A1**

**FRONT HUB  
REMOVER/REPLACER  
T81P-1104-C**

**HOLD WRENCH STATIONARY  
WHILE TURNING OTHER WRENCH**

**TURN THIS WRENCH  
COUNTERCLOCKWISE**