
REMOVAL AND INSTALLATION (Continued)

- Disconnect two connectors and antenna connector.
- 3. To install, reverse Removal procedure.





ltem	Part Number	Description
1 2 3	15K602 14A488 56903-S2	Remote Keyless Entry Module Wiring Harness Assembly Screw (3 Req'd)
4		Antenna Connector (part of 14A488 Wiring Harness Assembly) J1, J2 Connectors (part of 14A488 Wiring Harness
		Assembly)


TN9500A


Antenna

Removal and Installation

NOTE: This vehicle uses an antenna that is part of a wiring harness. DO NOT remove existing antenna from wire harness.

- Disconnect antenna connector from module and tape securely out of way.
- 2. Connect new antenna connector to module.
- 3. Install new antenna into vehicle, taping along wire harness path followed by old (unconnected) antenna. Secure using tie-wrap or tape.





	ltom	Part Number	Description	
	1	15K602	Remote Keyless Entry Module	
	2	14A488	Wiring Harness Assembly	
-	3	56903-S2	Screw (3 Req'd)	
	4		Antenna Connector (part of 14A488 Wiring Harness Assembly)	
	5		J1, J2 Connectors (part of 14A488 Wiring Harness Assembly)	

TN9500A