## **DIAGNOSIS AND TESTING (Continued)**

- In using the Pinpoint Tests, follow each Step in order, starting from the first Step in the appropriate test. Follow each Step until the fault is found.
- After completing any service to the IVSC system, verify that all components are properly reconnected and repeat the Quick Test.
- An open is defined as any resistance reading greater than 5 ohms unless otherwise specified.
- A short is defined as any resistance reading less than 10,000 ohms to ground, unless otherwise specified.

Refer to the following wiring diagram as necessary during Pinpoint testing. 1993 Taurus/Sable July, 1992