SECTION 13-07 Clock

SUBJECT PAGE	SUBJECT Qmalogod	PAGE
DESCRIPTION AND OPERATION Setting Time	REMOVAL AND INSTALLATION Clock	
DIAGNOSIS AND TESTING13-07-1	VEHICLE APPLICATION	

VEHICLE APPLICATION


Taurus/Sable.

DESCRIPTION AND OPERATION

The electronic digital clock displays time in a 12-hour format. Display dims when headlamps are on.

Setting Time

- Press and hold H button until desired hour is displayed.
- 2. Press and hold M button until desired minute is displayed.



DIAGNOSIS AND TESTING

The clock is serviced as an assembly. An inoperable clock should be removed and returned to a service center (shown on part number label on clock case) to be serviced. The clock will be replaced with a functioning clock.

NOTE: Display illuminates with the ignition switch in the ACC or RUN position.

