DIAGNOSIS AND TESTING (Continued)

DINPOINT TEST K: COMPACT DISC PLAYER IS INOPERATIVE OR INTERMITTENT (Continued)

pulsas permed		RESULT	ACTION TO TAKE
K8	CHECK CD PLAYER CHASSIS		
	 Check CD player chassis. Connect a known good speaker directly to CD player chassis. Verify operation of CD player. 	Yes	REPLACE speaker or connect, SERVICE or REPLACE speaker wiring as required.
	Does CD player operate properly?		NOTE: Use premium sound diagnostic chart to service if vehicle is so equipped.
		No. 1	Have CD player chassis serviced by authorized service center.

TK19305A

SPECIAL SERVICE TOOLS

ROTUNDA EQUIPMENT

 Model	Description
007-00035	EEC-IV Intermittent Ignition Analyzer