

DIAGNOSIS AND TESTING (Continued)

COMPONENT LOCATION (Continued)

TEST STEP		RESULT	ACTION TO TAKE
A1	STEP 1		
	<ul style="list-style-type: none"> Basic system operation. 	<p>Telephone will not turn on</p> <p>Unable to make a call</p> <p>An alternating tone signal (siren) sounds on your phone handset</p> <p>Audio feedback during Hands Free operation</p>	<ul style="list-style-type: none"> ENSURE ignition is ON. ENSURE PWR is ON. If not, press PWR button. CHECK modular connector on the handset cord to make sure that the handset is plugged in properly. ENSURE your phone is unlocked. ENSURE the NO SVC indicator is off. If it is on, you may be outside of a cellular service area. ENSURE you have pushed the SEND key after entering the number you are calling. CHECK your antenna system for problems: Bent or missing antenna, a loose or corroded antenna base, loose or damaged antenna cable. CHECK to see if you are "roaming". If so, FOLLOW roaming procedures in User's Manual. CHECK the display panel to make sure you've entered the correct number. If not, PRESS END, wait a few seconds and try the number again. REDUCE phone speaker volume.

NOTE: If you have difficulty placing your call, try several times. If all checks fail to solve the problem, call your local cellular carrier or call the Ford Cellular System at 1-800-367-3013 for assistance. If further assistance is required, go to your nearest Lincoln Dealer.

COMPONENT LOCATION

The following illustrations are provided to show component location only. Service to these components should only be done by the local cellular distributor.

