

26500

FORD

LINCOLN COUPES AND SEDANS 1988-00 REPAIR MANUAL

Covers all U.S. and Canadian models of
Lincoln Continental, Mark VII, Mark VIII
and Town Car



The First Step In Repair

INCLUDES
WIRING AND VACUUM
DIAGRAMS

CHILTON

FORD

LINCOLN COUPES AND SEDANS 1988-00 REPAIR MANUAL


CHILTON'S

Covers all U.S. and Canadian models of
Lincoln Continental, Mark VII, Mark VIII
and Town Car

by Joseph D'Orazio, A.S.E.

CHILTON *Automotive
Books*

PUBLISHED BY HAYNES NORTH AMERICA, Inc.



Manufactured in USA
© 2000 Haynes North America, Inc.
ISBN 0-8019-9314-8
Library of Congress Catalog Card No. 00-132-508
1234567890 9876543210

Haynes Publishing Group
Sparkford Nr Yeovil
Somerset BA22 7JJ England
Haynes North America, Inc
861 Lawrence Drive
Newbury Park
California 91320 USA

ABCDE
FGHIJ
KLMNO
PQ

6E1

Contents

1	GENERAL INFORMATION AND MAINTENANCE	1-2	HOW TO USE THIS BOOK	1-13	ROUTINE MAINTENANCE
		1-3	TOOLS AND EQUIPMENT	1-33	FLUIDS AND LUBRICANTS
		1-6	SERVICING YOUR VEHICLE SAFELY	1-45	JUMP STARTING A DEAD BATTERY
		1-7	FASTENERS, MEASUREMENTS AND CONVERSIONS	1-46	JACKING
		1-11	SERIAL NUMBER IDENTIFICATION		
2	ENGINE ELECTRICAL	2-2	DISTRIBUTOR IGNITION	2-8	CHARGING SYSTEM
		2-6	DISTRIBUTORLESS IGNITION SYSTEM	2-10	STARTING SYSTEM
		2-8	FIRING ORDERS	2-10	SENDING UNITS AND SENSORS
3	ENGINE AND ENGINE OVERHAUL	3-2	ENGINE MECHANICAL	3-43	ENGINE RECONDITIONING
		3-42	EXHAUST SYSTEM		
4	DRIVEABILITY AND EMISSION CONTROLS	4-2	EMISSION CONTROLS	4-17	TROUBLE CODES—EEC IV SYSTEM
		4-6	ELECTRONIC ENGINE CONTROLS	4-21	TROUBLE CODES—EEC V SYSTEM (OBD-II)
		4-14	COMPONENT LOCATIONS	4-27	VACUUM DIAGRAMS
5	FUEL SYSTEM	5-2	BASIC FUEL SYSTEM DIAGNOSIS	5-4	GASOLINE FUEL INJECTION SYSTEM
		5-2	FUEL LINES AND FITTINGS	5-11	FUEL TANK
6	CHASSIS ELECTRICAL	6-2	UNDERSTANDING AND TROUBLESHOOTING ELECTRICAL SYSTEMS	6-16	ENTERTAINMENT SYSTEMS
		6-7	BATTERY CABLES	6-19	WINDSHIELD WIPERS AND WASHERS
		6-7	AIR BAG (SUPPLEMENTAL RESTRAINT SYSTEM)	6-21	INSTRUMENTS AND SWITCHES
		6-9	HEATING AND AIR CONDITIONING	6-23	LIGHTING
		6-15	CRUISE CONTROL	6-29	CIRCUIT PROTECTION
				6-41	WIRING DIAGRAMS

Contents

7-2 AUTOMATIC TRANSMISSION **7-9** DRIVELINE
7-4 AUTOMATIC TRANSAXLE

DRIVE TRAIN

7

8-2 WHEELS **8-12** REAR SUSPENSION
8-4 FRONT SUSPENSION **8-18** STEERING

SUSPENSION
AND STEERING

8

9-2 BRAKE OPERATING SYSTEM **9-15** PARKING BRAKE
9-5 DISC BRAKES **9-16** ANTI-LOCK BRAKE SYSTEM
9-10 DRUM BRAKES

BRAKES

9

10-2 EXTERIOR **10-6** INTERIOR

BODY AND TRIM

10

11-2 TROUBLESHOOTING INDEX **11-6** DIAGNOSTIC PROCEDURES

TROUBLESHOOTING

11

11-25 GLOSSARY

GLOSSARY

11-29 MASTER INDEX

MASTER INDEX

SAFETY NOTICE

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles, as well as the personal safety of those performing repairs. This manual outlines procedures for servicing and repairing vehicles using safe, effective methods. The procedures contain many NOTES, CAUTIONS and WARNINGS which should be followed, along with standard procedures to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

It is important to note that repair procedures and techniques, tools and parts for servicing motor vehicles, as well as the skill and experience of the individual performing the work vary widely. It is not possible to anticipate all of the conceivable ways or conditions under which vehicles may be serviced, or to provide cautions as to all possible hazards that may result. Standard and accepted safety precautions and equipment should be used when handling toxic or flammable fluids, and safety goggles or other protection should be used during cutting, grinding, chiseling, prying, or any other process that can cause material removal or projectiles.

Some procedures require the use of tools specially designed for a specific purpose. Before substituting another tool or procedure, you must be completely satisfied that neither your personal safety, nor the performance of the vehicle will be endangered.

Although information in this manual is based on industry sources and is complete as possible at the time of publication, the possibility exists that some car manufacturers made later changes which could not be included here. While striving for total accuracy, the authors or publishers cannot assume responsibility for any errors, changes or omissions that may occur in the compilation of this data.

PART NUMBERS

Part numbers listed in this reference are not recommendations by Haynes North America, Inc. for any product brand name. They are references that can be used with interchange manuals and aftermarket supplier catalogs to locate each brand supplier's discrete part number.

SPECIAL TOOLS

Special tools are recommended by the vehicle manufacturer to perform their specific job. Use has been kept to a minimum, but where absolutely necessary, they are referred to in the text by the part number of the tool manufacturer. These tools can be purchased, under the appropriate part number, from your local dealer or regional distributor, or an equivalent tool can be purchased locally from a tool supplier or parts outlet. Before substituting any tool for the one recommended, read the SAFETY NOTICE at the top of this page.

ACKNOWLEDGMENTS

This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission from Ford Motor Company.

All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.

While every attempt is made to ensure that the information in this manual is correct, no liability can be accepted by the authors or publishers for loss, damage or injury caused by any errors in, or omissions from, the information given.
