

DESCRIPTION AND OPERATION (Continued)

If a tethered safety seat is installed in the front seat, the tether strap should be hooked to the rear seat lap belt tongue or the webbing of the buckled rear seat lap belt behind the child safety seat. Attachment holes (at each rear seating position) have been provided to attach the tether anchor hardware kit.

WARNING: WHEN USING ANY INFANT OR CHILD RESTRAINT SYSTEM IT IS IMPORTANT THAT YOU FOLLOW THE INSTRUCTIONS PROVIDED BY THE MANUFACTURER CONCERNING ITS INSTALLATION AND USE. FAILURE TO FOLLOW EACH OF THE RESTRAINT MANUFACTURER'S INSTRUCTIONS CAN RESULT IN A CHILD STRIKING THE VEHICLE'S INTERIOR DURING A SUDDEN STOP OR COLLISION.

WARNING: IT IS IMPORTANT THAT THE BOLT/ANCHOR BE SECURELY TIGHTENED TO SPECIFICATION. OTHERWISE, THE CHILD SAFETY SEAT MAY NOT BE PROPERLY SECURED AND THE CHILD COULD BE INJURED IN CASE OF A SUDDEN STOP OR ACCIDENT.

WARNING: DO NOT PLACE INFANT OR CHILD SEATS IN THE AUXILIARY (THIRD) SEAT, BECAUSE THEY MAY NOT PROVIDE ADEQUATE PROTECTION FROM PERSONAL INJURY IN THE CASE OF A COLLISION.

LOCATION

Dimension A is the distance from the center line of the vehicle to the center of the attachment holes.
Dimension B is the approximate distance from the center of the radio speaker grille opening to the center of the tether attachment holes.

Vehicle	Dimension A — Centerline to Tether Hole		Dimension B — Speaker Grille Opening to Tether Hole		Hole Size	
	mm	inches	mm	inches	mm	inches
Taurus Outboard Location	380	15.0	222	8.75	9.0	0.35
Sable Outboard Location	380	15.0	222	8.75	9.0	0.35
Taurus Inboard Location	150	6.0	203	8.0	9.0	0.35
Sable Inboard Location	150	6.0	203	8.0	9.0	0.35

CR4383-C