


DESCRIPTION AND OPERATION (Continued)

(Continued)


Airflow Chart 2 (VENT, FLOOR, MIX, DEFROST)



**CONTROL ASSEMBLY KNOBS**

NOTE: (1) NO REFRIGERATION CAN BE INTRODUCED WHEN THE SELECTOR KNOB IS IN THE VENT POSITION.  
 (2) THE TEMPERATURE SELECTOR MAY BE ROTATED TO HEAT OR COOL THE AIR FLOW AS DESIRED.


SYSTEM AIR FLOW SCHEMATIC - SELECTOR KNOB IN "VENT" POSITION



**CONTROL ASSEMBLY KNOBS**

NOTE: A SLIGHT AMOUNT OF HEATED AIR BY-PASSES THE FLOOR PANEL DOOR AND IS DIRECTED TO THE DEFROSTER.


SYSTEM AIR FLOW SCHEMATIC - SELECTOR KNOB IN "FLOOR" POSITION



**CONTROL ASSEMBLY KNOBS**

NOTE: THE A/C CLUTCH IS OPERATING TO DEHUMIDIFY THE AIR AND MINIMIZE WINDSHIELD FOGGING.

SYSTEM AIR FLOW SCHEMATIC - SELECTOR KNOB IN "MIX" POSITION



**CONTROL ASSEMBLY KNOBS**

NOTE: (1) THERE IS A SLIGHT AIR BLEED TO THE FLOOR REGISTERS  
 (2) TEMPERATURE KNOB SETTING DETERMINES THE AMOUNT OF HEAT BEING INTRODUCED INTO THE SYSTEM  
 (3) THE A/C CLUTCH IS OPERATING TO DEHUMIDIFY THE AIR AND MINIMIZE WINDSHIELD FOGGING

SYSTEM AIR FLOW SCHEMATIC - SELECTOR KNOB IN "DEFROST" POSITION

CCL 2610-E